

Moxa Managed Switch TSN-G5000 Series Command Line Interface

Version 1.0, July 2020

www.moxa.com/product

Models covered by this user's manual:
TSN-G5000 Series Managed Ethernet Switches

MOXA®

© 2020 Moxa Inc. All rights reserved.

Moxa Managed Switch TSN-G5000 Series

Command Line Interface

The software described in this manual is furnished under a license agreement and may be used only in accordance with the terms of that agreement.

Copyright Notice

© 2020 Moxa Inc. All rights reserved.

Trademarks

The MOXA logo is a registered trademark of Moxa Inc.

All other trademarks or registered marks in this manual belong to their respective manufacturers.

Disclaimer

Information in this document is subject to change without notice and does not represent a commitment on the part of Moxa.

Moxa provides this document as is, without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. Moxa reserves the right to make improvements and/or changes to this manual, or to the products and/or the programs described in this manual, at any time.

Information provided in this manual is intended to be accurate and reliable. However, Moxa assumes no responsibility for its use, or for any infringements on the rights of third parties that may result from its use.

This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

Technical Support Contact Information

www.moxa.com/support

Moxa Americas

Toll-free: 1-888-669-2872
Tel: +1-714-528-6777
Fax: +1-714-528-6778

Moxa Europe

Tel: +49-89-3 70 03 99-0
Fax: +49-89-3 70 03 99-99

Moxa India

Tel: +91-80-4172-9088
Fax: +91-80-4132-1045

Moxa China (Shanghai office)

Toll-free: 800-820-5036
Tel: +86-21-5258-9955
Fax: +86-21-5258-5505

Moxa Asia-Pacific

Tel: +886-2-8919-1230
Fax: +886-2-8919-1231

Table of Contents

1. About This Manual.....	1-1
2. Understanding the Command Line Interface	2-1
Accessing the Switch.....	2-2
Logging in using the RS-232 Console	2-2
Logging in using Telnet	2-5
Command Modes	2-7
Basic Configuration.....	2-7
Understanding All Command Modes	2-7
Help Messages	2-8
Special Usage and Limitations	2-9
Abbreviated Commands.....	2-9
No and Default Forms of Commands	2-10
CLI Error Messages	2-11
Command History.....	2-11
3. Commands	3-1
System.....	3-2
System Management	3-2
Account Management.....	3-6
Network	3-9
Time.....	3-18
Port	3-26
Port Interface	3-26
Layer 2 Switching	3-31
VLAN	3-31
MAC	3-42
Multicast	3-44
Network Redundancy	3-46
Layer 2 Redundancy	3-46
Management	3-55
Network Management	3-55
Security.....	3-68
Device Security.....	3-68
Network Security.....	3-77
Authentication	3-79
Diagnostics	3-81
System Status	3-81
Event Notification	3-83
Diagnosis	3-90
Maintenance and Tool	3-98

1

About This Manual

This chapter describes how to use the command line to configure Moxa's managed Ethernet switches. Besides the web interface configuration, the command line interface helps system administrators easily and quickly manage, monitor, and configure Moxa's managed Ethernet switch.

2

Understanding the Command Line Interface

This chapter helps users understand the command line interface, and demonstrates a general ideal on the command line operation.

The following topics are covered in this chapter:

- Accessing the Switch**
 - Logging in using the RS-232 Console
 - Logging in using Telnet
- Command Modes**
 - Basic Configuration
 - Understanding All Command Modes
- Help Messages**
- Special Usage and Limitations**
- Abbreviated Commands**
- No and Default Forms of Commands**
- CLI Error Messages**
- Command History**

Accessing the Switch


Users can connect to the switch using one of two methods: by console or by Telnet.

Logging in using the RS-232 Console

The Moxa managed switch features an RJ45 serial console port to allow users to connect to the switch and configure settings.


NOTE Moxa recommends using PComm Terminal Emulator for serial communication. This software is available for free on the Moxa website. You can use other serial communication software, but the following instructions may be different.

1. Prepare the included RS-232 serial cable with RJ45 interface.
2. Connect the RJ45 interface end to the console port on the switch, and the other end to the computer.
3. Download the **PComm Terminal Emulator** from the Moxa website and install the software.
4. In Windows, click **Start > Moxa > PComm Terminal Emulator**.




5. Click **Port Manager > Open** to establish a new connection.


The Property window will appear.




6. On the **Communication Parameter** tab, select the COM port that will be used for the console connection. Configure the fields as follows: **115200** for **Baud rate**, **8** for **Data bits**, **None** for **Parity**, and **1** for **Stop bits**.



7. On the **Terminal** tab, select **VT100** as the **Terminal Type**, and click **OK** to continue.



8. Log in to the console using the default login name **admin** and password **moxa**. This password will be required to access any of the consoles (web, serial, Telnet).



9. When successfully connected to the switch, you can start configuring the switch parameters by using command line instructions.

NOTE By default, the password assigned to the Moxa switch is **moxa**. We recommended changing the default password after logging in for the first time to help keep your system secure.

Logging in using Telnet


Opening the Moxa switch's Telnet or web console over a network requires that the PC host and Moxa switch are on the same logical subnet. You may need to adjust your PC host's IP address and subnet mask. By default, the Moxa switch's IP address is **192.168.127.253** and the subnet mask is **255.255.255.0**. Your PC's IP address must be configured with an IP in the 192.168.127.xxx and a subnet mask 255.255.255.0.

NOTE When connecting to the Moxa switch's through Telnet or the web console, first connect one of the Moxa switch's Ethernet ports to your Ethernet LAN, or directly to your PC's Ethernet port. You may use either a straight-through or cross-over Ethernet cable.


NOTE The Moxa switch's default IP address is 192.168.127.253 with subnet mask 255.255.255.0.

After making sure that the Moxa switch is connected to the same LAN and logical subnet as your PC, open the Moxa switch's Telnet console as follows:


1. In Windows, click **Start > Run**.



2. In the Windows Run window, enter **telnet** followed by the Moxa switch's IP address (192.168.127.253). You can also issue the Telnet command from a DOS prompt.



3. Log in to the Telnet console using the default login name **admin** and password **moxa**. This password will be required to access any of the consoles (web, serial, Telnet).



4. When successfully connected to the switch, you can start configuring the switch parameters by using command line instructions.

NOTE By default, the password assigned to the Moxa switch is **moxa**. We recommended changing the default password after logging in for the first time to help keep your system secure.

Command Modes

Basic Configuration

The CLI (Command Line Interface) for Moxa's Managed switches can be accessed through either the serial console or the Telnet console. For either type of connection, access to the CLI is generally referred to as an EXEC session.

The CLI is organized using different configuration levels. When you first enter the CLI, type "?" to view a list of basic commands and a description of each function. Type any of the commands shown on the screen to access the next configuration level. The help panel can be accessed from any configuration level by typing "?". The switch will show all the commands for the current configuration mode.

```
moxa# ?
clear          Clear the specified parameters
cli           Configure the CLI display parameters
configure      Enter configuration mode
copy           Perform copy operation
end            Exit to the privileged Exec (#) mode
exit           Exit the session
help            Display help for the command
locator         Activate device locator so that the LED on the
                device blinks
logout         Terminate the session
ping           Ping a target to check its status
relay           Relay related command
reload          Halt and perform a warm restart
show            Display configuration / statistics / general
                information

moxa# ■
```

Understanding All Command Modes

The Moxa switch's CLI supports multiple types of configuration levels for performing different functions. Refer to the following table for an overview of all available modes.

Mode	Access Method	Prompt	Exit Method	About This Mode
User EXEC	Begin a new session and login as user .	moxa>	Enter the exit command. This will return you to the previous configuration mode.	Use this mode to display system information.
Privileged EXEC	Begin a session and login as admin .	moxa #	Enter the exit command. This will return you to the previous configuration mode.	Use this mode to verify commands that you have entered.
Global configuration	Enter the configure command while in Privileged EXEC mode.	moxa (config)#	Enter the exit command. This will return you to the previous configuration mode.	Use this mode to configure parameters that will apply to the entire switch.
Interface configuration	While in global configuration mode, enter the interface command, followed	moxa (config-if)#	Enter the exit command. This will return you to the previous configuration mode.	Use this mode to configure parameters for the specified interface.

	by an interface identification.			
--	---------------------------------	--	--	--

Refer to the following example of changing configuration modes below.

Type **config** at the command prompt to enter configuration mode.

```
moxa# config
moxa(config)#
```

Type **exit** to return to the previous configuration mode.

```
moxa(config)# exit
moxa#
```

Type **end** from within any configuration level to return to privileged Exec mode.

```
moxa(config)# end
moxa#
```

Help Messages

The CLI supports several types of interactive commands. The **Help** commands are listed in the following table:

Command	Purpose
?	Shows a brief description of the Help feature in any command level.
Partial command?	Shows a list of commands that begin with the entered character string. There should be no space between the command and the question mark.
Partial command<Tab>	Completes a partially entered command name. There should be no space between the command and <Tab>.
Command ?	Shows the keywords, arguments, or both associated with the command. There should be a space between the command and the question mark.
Command keyword ?	Shows the arguments that are associated with the keyword. There should be a space between the command and the keyword, and between the keyword and the question mark.

Special Usage and Limitations

If the command contains any special characters, such as *, #, and %, you need to use the quotation marks ("") to cover these special characters. Refer to the following figure for an example.

```
moxa(config)# contact "test#"
moxa(config)# exit
moxa# show run
Building user configuration ...

!
! Time: 2019-08-30 18:37:01
! Model name: MDS-G4028
! Firmware version: v0.4 Build 2019_0703_1227
! Product revision: V255.255.255
! IP address: 192.168.127.253
! MAC address: 00:01:02:03:04:05
! Serial number: MOXA00000000
! Module M2 product revision: None
! Module M3 product revision: None
! Module M4 product revision: None
! Module M5 product revision: None
! Module M6 product revision: None
! Module M7 product revision: None
!
configure terminal
contact "test#"
interface ethernet 1/1
!
interface ethernet 1/2
--More--
```

In addition, you may use a semicolon mark (;) to separate several commands. Refer to the figure below for an example.

```
moxa(config)# hostname test;contact test2
moxa(config)#
test(config)#
```

Abbreviated Commands

The exclamation mark (!) can be used to enter the global configuration mode, as shown in the example below.

```
moxa# !
moxa(config)#
moxa(config)#
```

In addition, you can input one or more letters to quickly see all commands starting with these letters. For example, type **c?**, all commands starting with c will be shown. Refer to the figure below as the example.

```
moxa# c?
clear
cli
configure
copy
```

In addition, when pressing **Tab** after typing the prefix letter, the syntax of the commands starting with that letter will be shown. See the figure below for details.

```
moxa# c
EXEC commands :

  clear logging event-log
  clear screen
  clear spanning-tree detected protocols interface { <interface-type> <interface
-id> | port-channel <integer> }
  clear statistics [interfaces {port-channel <integer> | <interface-type> <inter
face-id> }]
  cli eth-index-naming { modular | non-modular }
  cli pagination turn {on | off}
  configure [ terminal ]
  copy event-log {tftp://server/filename | sftp://<user-name>:<pass-word>@server
/filename}
  copy running-config startup-config
  copy running-config {tftp://server/filename | sftp://<user-name>:<pass-word>@s
erver/filename} [included-default] [password <string(60)>]
  copy startup-config {tftp://server/filename | sftp://<user-name>:<pass-word>@s
erver/filename} [included-default] [password <string(60)>]
  copy { tftp://server/filename running-config | sftp://<user-name>:<pass-word>@s
erver/filename running-config } [password decrypt-password]
  copy { tftp://server/filename | sftp://<user-name>:<pass-word>@server/filename
--More--■
```

No and Default Forms of Commands

A “**no**” command can be used to perform the “delete”, “disable”, or “reset to default” functions. Type “**no ?**” to check how parameters can be used.

```
moxa(config)# no ?

contact          Reset the contact information of the device
description      Reset the description of the device
dot1x           Configure dot1x parameters
event-notification Configure event notification parameters
hostname         Reset the hostname of the device
interface        Configure interface parameters
ip               Configure IP parameters
ipv6             Configure IPv6 parameters
lldp             Configure LLDP parameters
location         Reset the location information of the device
logging          Configure logging parameters
logging-server   Logging server parameters
login            Configure login related configuration
mac-address-table Configure MAC address table parameters
management       Configure management parameters
monitor          Configure Port Mirror parameters
ntp               Configure NTP/SNTP parameters
poe              Configure PoE parameters
port-channel     Configure port-channel parameters
radius-server    Configure RADIUS server configuration
--More--■
```

The following example shows how a “**no**” command can run the “reset to default” function.

```
moxa(config)# hostname test
moxa(config)#
test(config)# no hostname
test(config)#
moxa(config)#
--More--■
```

The following example shows how “**no**” can run the “disable” function.

```
moxa(config-if)# gvrp
moxa(config-if)# no gvrp
moxa(config-if)#
--More--■
```

CLI Error Messages

You may encounter some error messages while configuring Moxa's Ethernet switch. Refer the following table for an overview of error messages and solutions.

Error Message	Meaning	Solution
% Ambiguous command	The characters you entered are insufficient for the switch to recognize the command.	Re-enter the command with a space between the command and the question mark (?). The possible keywords with the command will appear.
% Incomplete command	The keywords or values you entered are incomplete.	Re-enter the command with a space between the command and the question mark (?). The possible keywords with the command will appear.
% Invalid input detected at '^' marker.	The command you entered is incorrect. The point of invalid input will be indicated by a caret (^).	Enter a question mark (?) to display all the available commands in this command mode. The possible keywords with the command will appear.

Command History

Use the Up arrow and Down arrow keys to show to cycle through the history of previously entered commands.

Pressing the Up arrow will display the previously entered command. Pressing the Down arrow will display the next command in the history.

3

Commands

This chapter covers all commands for users to configure Moxa's managed Ethernet switch.

The following topics are covered in this chapter:

□ System

- System Management
- Account Management
- Network
- Time

□ Port

- Port Interface

□ Layer 2 Switching

- VLAN
- MAC
- Multicast

□ Network Redundancy

- Layer 2 Redundancy

□ Management

- Network Management

□ Security

- Device Security
- Network Security
- Authentication

□ Diagnostics

- System Status
- Event Notification
- Diagnosis
- Maintenance and Tool

System

System Management

Information Setting

Configure Device Hostname

Commands

hostname text

no hostname

Syntax Description	no	Remove configuration/delete entry/reset to default value
	hostname	Configure the device hostname parameters
	device-name	The hostname of the device consisting of lower case letters, numbers, and hyphens
Defaults	hostname: moxa	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	<pre>moxa# configure terminal moxa(config)# hostname device-name device-name(config)# no hostname moxa(config)#</pre>	
Error Messages	N/A	
Related Commands	N/A	

Configure Device Description

Commands

description text

no description

Syntax Description	no	Remove configuration/delete entry/reset to default value
	description	Configure the device description parameters
	text	The description of the device
Defaults	N/A	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	<pre>moxa# configure terminal moxa(config)# description "description data" moxa(config)# no description</pre>	
Error Messages	N/A	
Related Commands	N/A	

Configure Contact Information

Commands

contact text

no contact

Syntax Description	no	Remove configuration/delete entry/reset to default value
	contact	Configure device contact information
	text	The contact information of the device
Defaults	N/A	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	moxa# configure terminal moxa(config)# contact "contact info" moxa(config)# no contact	
Error Messages	N/A	
Related Commands	N/A	

Show Location Information

Commands

location text

no location

Syntax Description	no	Remove configuration/delete entry/reset to default value
	location	Configure the device location information
	text	The location information of the device
Defaults	N/A	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	moxa# configure terminal moxa(config)# location "location info" moxa(config)# no location	
Error Messages	N/A	
Related Commands	N/A	

Show System Information

Commands

show system information

Syntax Description	show	Display configuration/status information
	system	Display system information
	information	Display system information
Defaults	N/A	
Command Modes	User EXEC Privileged EXEC	
Usage Guidelines	N/A	
Examples	<pre>moxa# show system information</pre> <pre>Hardware Version : V0.0.0 Firmware Version : v0.3 build 2019_050202111 Device Contact : Device Name : moxa Device Location : Device Description : Device Uptime : 0 Days, 1 Hrs, 35 Mins, 21 Secs Login Authentication Mode : Local</pre>	
Error Messages	N/A	
Related Commands	N/A	

Firmware Upgrade

Upgrade the Firmware

Commands

copy { tftp_url | sftp_url } device-firmware

Syntax Description	copy	Copy the target file or input
	device-firmware	The system firmware
	tftp_url	The address of the remote TFTP server in the format "tftp://server/filename"
	sftp_url	The address of the remote SFTP server in the format "sftp://username:password@server/filename"
Defaults	N/A	
Command Modes	Privileged EXEC	
Usage Guidelines	N/A	
Examples	<pre>moxa# copy tftp://192.168.127.2/FWR_TSN-G5000_v0.1_2019_0904_1452.rom device-firmware</pre>	
Error Messages	N/A	
Related Commands	N/A	

Configuration Backup and Restore

Copy Running Configuration

Commands

copy running-config { <tftp_url> | <sftp_url> [included-default] [password <string (60)>] }

copy { <tftp_url> | <sftp_url> } running-config password <string 60>}

Syntax Description	copy Copy the target file or input running-config The running configuration to be copied tftp_url The location of the file to be copied on the remote TFTP server sftp_url The location of the file to be copied on the remote SFTP server included-default Include default configurations in the configuration file password The password for the default username <string (60)> The length of the password (max. 60 characters)
Defaults	N/A
Command Modes	Privileged EXEC
Usage Guidelines	N/A
Examples	<pre>moxa# copy running-config tftp://192.168.127.2/config.ini included-default password 12345 moxa# copy tftp://192.168.127.2/config.ini running-config password 12345</pre>
Error Messages	N/A
Related Commands	N/A

Copy Startup Configuration

Commands

copy startup-config { <tftp_url> | <sftp_url> [included-default] [password <string (60)>] }

Syntax Description	copy Copy the target file or input startup-config The startup configuration to be copied tftp_url The location of the file to be copied on the remote TFTP server sftp_url The location of the file to be copied on the remote SFTP server included-default Include default configurations in the configuration file password The password for the default username <string (60)> The length of the password (max. 60 characters)
Defaults	N/A
Command Modes	Privileged EXEC
Usage Guidelines	N/A
Examples	<pre>moxa# copy startup-config tftp://192.168.127.2/config.ini included-default password 12345</pre>
Error Messages	N/A
Related Commands	N/A

Account Management

User Account

Configure User Account Setting

Commands

```
username <username> password <passwd> group { admin | user | supervisor } status { enable | disable } email <email>
no username username
```

Syntax Description	no username username password password group group status enable disable email email	Remove configuration/delete entry/reset to default value Configures username parameters The username to be used for login Configures password parameters The password to be entered by the user Configures the user privilege level Valid values are "admin", "supervisor", and "user" "admin" for admin group, "supervisor" for supervisor, and "user" for normal user group Configures user status parameters Enable the user Disable the user Configures the user email The user's email address
Defaults	N/A.	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	(config)# username testuser password test123 group admin status enable email test@test.com	
Error Messages	% Max User Account Amount Reached % Invalid Username Format % Password doesn't comply with password rules. % Invalid Email Format % Invalid Password Format % User does not exist % At least one admin should be active. % User status cannot be updated by self. % User Deletion Failed % User cannot be disabled by self % User cannot be modified group by self % User cannot be deleted by self	
Related Commands	Show user	

Show User Information

Commands

show user

Syntax Description	show	Display running information for the function
	user	Display user parameters
Defaults	N/A	
Command Modes	Global configuration/ User EXEC	
Usage Guidelines	N/A	
Examples	<pre># show user USER ACTIVE PRIVILEGE EMAIL admin 1 admin admin@sample.com user 1 user user@sample.com supervisor 1 supervisor supervisor@sample.com</pre>	
Error Messages	N/A	
Related Commands	username	

Password Policy

Configure Password Maximum Lifetime

Commands

password max-life-time [<days (0-365)>]

Syntax Description	password	Configure password parameters
	max-life-time	Configure the maximum lifetime of the password
	days	Maximum lifetime in days; a 0 or "no" value means it does not expire
Defaults	0	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	<pre>moxa# config moxa(config)# password max-life-time 30 moxa(config)# password max-life-time</pre>	
Error Messages	N/A	
Related Commands	show password max-life-time	

Configure Password Validation Rules

Commands

password validate-rules [lowercase] [uppercase] [numbers] [symbols]

Syntax Description	password	Configure password parameters
	validate-rules	Configure validation rules
lowercase		Configure at least 1 lowercase flag for password validation
uppercase		Configure at least 1 uppercase flag for password validation
numbers		Configure at least 1 numbers flag for password validation
symbols		Configure at least 1 symbols flag for password validation
Defaults	There are no validation rules configured by default	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	<pre>moxa# config moxa(config)# password validate-rules lowercase numbers moxa(config)# password validate-rules</pre>	
Error Messages	N/A	
Related Commands	show password validate-rules	

Configure Password Minimum Length

Commands

password minimum-length <minimum-len (4-63)>

Syntax Description	password	Configure password parameters
	minimum-length	Configure the minimum password length
	minimum-len	The minimum password length
Defaults	4	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	<pre>moxa# config moxa(config)# password minimum-length 8</pre>	
Error Messages	N/A	
Related Commands	show password minimum-length	

Show Password Minimum Length

Commands

show password minimum-length

Syntax Description	show	Display running information for the function
	password	Display password parameters
	minimum-length	Display the minimum length of the password
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	<pre>moxa# show password minimum-length 8</pre>	
Error Messages	N/A	
Related Commands	password minimum-length	

Show Password Validation Rules

Commands

show password validate-rules

Syntax Description	show	Display running information for the function
	password	Display password parameters
	validate-rules	Display the password validation rules
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	moxa# show password validate-rules	
Error Messages	N/A	
Related Commands	password validate-rules	

Network

IP Configuration

Configure IP Management Address

Commands

ip management address { dhcp | ipv4-address ipv4-netmask [ipv4-gateway] }

Syntax Description	ip	Configure IP parameters
	management	Configure IPv4 management address parameters
	address	Configure the IPv4 management address of the device
	dhcp	Assign the IPv4 address by DHCP
	ipv4-address	The IPv4 address
	ipv4-netmask	The IPv4 subnet mask
	ipv4-gateway	The IPv4 gateway
Defaults	ipv4-address: 192.168.127.253 ipv4-netmask: 255.255.255.0 ipv4-gateway: 0.0.0.0	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	moxa# configure terminal moxa(config)# ip management address dhcp moxa(config)# ip management address 10.1.1.1 255.255.255.0 10.1.1.254	
Error Messages	Invalid: Invalid IPv4 Management Address ipv4-address/ipv4-netmask. Invalid: Gateway ipv4-gateway is not reachable.	
Related Commands	N/A	

DHCP Server

Show IP DHCP

Commands

show ip dhcp [{ binding | static | port-based-ip-assignment }]

Syntax Description	show Display configuration/status information ip Display IP information dhcp Display DHCP server information binding Display binding information static Display MAC-based IP assignment information port-based-ip-assignment Display port-based IP assignment information
Defaults	N/A
Command Modes	User EXEC Privileged EXEC
Usage Guidelines	N/A
Examples	<pre>moxa# show ip dhcp DHCP Server Mode: DHCP / MAC-based IP Assignment DHCP Pool List ----- Index : 1 State : Enable First IP Address : 192.168.127.10 Last IP Address : 192.168.127.20 Netmask : 255.255.255.0 Lease Time (secs) : 86400 Default Gateway : NTP Server : DNS Server 1 : DNS Server 2 : moxa# show ip dhcp binding Host Name IP Address MAC Address Time Left ----- VirtualBox 192.168.127.10 08:00:27:f6:bf:98 23 h: 59 m: 55 s // A MAC-based IP assignment is created moxa# show ip dhcp static DHCP Server Mode: DHCP / MAC-based IP Assignment MAC-based IP Assignment List ----- Index : 1 State : Enable Host Name : host1 Host IP Address : 192.168.127.30 Host Netmask : 255.255.255.0 MAC Address : 08:00:27:f6:bf:98 Lease Time (secs) : 86400 Default Gateway : NTP Server : DNS Server 1 : DNS Server 2 :</pre>

	<pre> moxa# show ip dhcp binding Host Name IP Address MAC Address Time Left ----- host1 192.168.127.30 08:00:27:f6:bf:98 (static) // A Port-based IP assignment is created moxa# show ip dhcp port-based-ip-assignment DHCP Server Mode: Port-based IP Assignment Port-based IP Assignment List ----- Port : 2 State : Enable Static IP Address : 192.168.127.40 Host Netmask : 255.255.255.0 Lease Time (secs) : 86400 Default Gateway : NTP Server : DNS Server 1 : DNS Server 2 : moxa# show ip dhcp binding Host Name IP Address MAC Address Time Left ----- 192.168.127.40 (static) </pre>
Error Messages	N/A
Related Commands	N/A

Configure/Disable DHCP Server Mode

Commands

dhcp-server mode disable

dhcp-server mode dhcp-and-mac-based-ip-assignment

Syntax Description	dhcp-server Configure DHCP server parameters mode Configure DHCP server mode parameters disable Disable the DHCP server dhcp-and-mac-based-ip-assignment Standard DHCP server and MAC-based DHCP
Defaults	N/A
Command Modes	Privileged EXEC Global Configuration
Usage Guidelines	N/A
Examples	<pre> moxa# config moxa(config)# dhcp-server mode disable </pre>
Error Messages	N/A
Related Commands	N/A

Enable/Disable IP DHCP Pool

Commands

ip dhcp pool <integer> [{ enable | disable }]

Syntax Description	ip	Configure IP parameters
	dhcp	Configure DHCP server parameters
	pool	Configure address pool parameters
	<integer>	Pool number
	enable	Enable the address pool
	disable	Disable the address pool
Defaults	N/A	
Command Modes	Privileged EXEC Global Configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# ip dhcp pool 1 enable moxa(dhcp-config)#	
Error Messages	N/A	
Related Commands	N/A	

Remove IP DHCP Pool

Commands

no ip dhcp pool <integer>

Syntax Description	no	Remove configuration/delete entry/reset to default value
	ip	Configure IP parameters
	dhcp	Configure DHCP server parameters
	pool	Configure address pool parameters
	<integer>	The address pool number
Defaults	N/A	
Command Modes	Privileged EXEC Global Configuration	
Usage Guidelines	N/A	
Examples	moxa# no ip dhcp pool 1	
Error Messages	N/A	
Related Commands	N/A	

Enable/Disable IP DHCP Static Pool

Commands

ip dhcp static pool <string (63)> [{ enable | disable }]

Syntax Description	ip	Configure IP parameters
	dhcp	Configure DHCP server parameters
	static	Configure MAC-based IP assignment parameters
	pool	Configure address pool parameters
	<string (63)>	The client host name (DHCP option 12)
	enable	Enable the address pool
	disable	Disable the address pool
Defaults	N/A	
Command Modes	Privileged EXEC Global Configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# ip dhcp static pool host1 enable moxa(dhcp-config)#	
Error Messages	N/A	
Related Commands	N/A	

Remove IP DHCP Static Pool

Commands

no ip dhcp static pool <string (63)>

Syntax Description	no	Remove configuration/delete entry/reset to default value
	ip	Configure IP parameters
	dhcp	Configure DHCP server parameters
	static	Configure MAC-based IP assignment parameters
	pool	Configure address pool parameters
	<string (63)>	The client host name (DHCP option 12)
Defaults	N/A	
Command Modes	Privileged EXEC Global Configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# no ip dhcp static pool host1	
Error Messages	N/A	
Related Commands	N/A	

DHCP and MAC-based IP Assignment

Configure DHCP Server Pool

Commands

network <ucast_addr> <ucast_addr> <ip_mask>

Syntax Description	network	Configure network parameters
	<ucast_addr>	The address pool starting IP address
	<ucast_addr>	The address pool ending IP address
	<ip_mask>	The subnet mask
Defaults	N/A	
Command Modes	Privileged EXEC DHCP Configuration	
Usage Guidelines	N/A	
Examples	moxa(dhcp-config)# network 192.168.127.10 192.168.127.20 255.255.255.0	
Error Messages	N/A	
Related Commands	N/A	

Configure DHCP Server Host IP Address

Commands

host <ucast_addr> <ip_mask>

Syntax Description	host	Configure host parameters
	<ucast_addr>	The unicast IP address
	<ip_mask>	The subnet mask
Defaults	N/A	
Command Modes	Privileged EXEC DHCP Configuration	
Usage Guidelines	N/A	
Examples	moxa(dhcp-config)# host 192.168.127.100	
Error Messages	N/A	
Related Commands	N/A	

Configure DHCP Server Host MAC Address

Commands

hardware-address <ucast_mac>

Syntax Description	hardware-address	Configure the MAC address
	<ucast_mac>	The MAC address
Defaults	N/A	
Command Modes	Privileged EXEC DHCP Configuration	
Usage Guidelines	N/A	
Examples	moxa(dhcp-config)# hardware-address 00:90:e8:11:22:33	
Error Messages	N/A	
Related Commands	N/A	

Configure Lease Time

Commands

lease <integer (10-604800)>

Syntax Description	lease	Configure the IP lease duration
	<integer (10-604800)>	The IP lease duration in seconds
Defaults	N/A	
Command Modes	Privileged EXEC DHCP Configuration	
Usage Guidelines	N/A	
Examples	moxa(dhcp-config)# lease 3600	
Error Messages	N/A	
Related Commands	N/A	

Reset Lease time

Commands

no lease

Syntax Description	no	Remove configuration/delete entry/reset to default value
	lease	Configure the IP lease duration
Defaults	N/A	
Command Modes	Privileged EXEC DHCP Configuration	
Usage Guidelines	N/A	
Examples	moxa(dhcp-config)# no lease	
Error Messages	N/A	
Related Commands	N/A	

Configure Default Router IP Address

Commands

default-router <ucast_addr>

Syntax Description	default-router	Configure the default router
	<ucast_addr>	The unicast IP address
Defaults	N/A	
Command Modes	Privileged EXEC DHCP Configuration	
Usage Guidelines	N/A	
Examples	moxa(dhcp-config)# default-router 192.168.127.254	
Error Messages	N/A	
Related Commands	N/A	

Remove Default Router IP Address

Commands

no default-router

Syntax Description	no	Remove configuration/delete entry/reset to default value
	default-router	Configure the default router
Defaults	N/A	
Command Modes	Privileged EXEC DHCP Configuration	
Usage Guidelines	N/A	
Examples	moxa(dhcp-config)# no default-router	
Error Messages	N/A	
Related Commands	N/A	

Configure DNS Server IP Address

Commands

dns-server <ucast_addr> [<ucast_addr>]

Syntax Description	dns-server	Configure the DNS server
	<ucast_addr>	The unicast IP address
	<ucast_addr>	The unicast IP address
Defaults	N/A	
Command Modes	Privileged EXEC DHCP Configuration	
Usage Guidelines	N/A	
Examples	moxa(dhcp-config)# dns-server 192.168.127.254 moxa(dhcp-config)# dns-server 192.168.127.251 192.168.127.252	
Error Messages	N/A	
Related Commands	N/A	

Remove DNS Server IP Address

Commands

no dns-server

Syntax Description	no	Remove configuration/delete entry/reset to default value
	dns-server	Configure the DNS server
Defaults	N/A	
Command Modes	Privileged EXEC DHCP Configuration	
Usage Guidelines	N/A	
Examples	moxa(dhcp-config)# no dns-server	
Error Messages	N/A	
Related Commands	N/A	

Configure NTP Server IP Address

Commands

ntp-server <ucast_addr>

Syntax Description	ntp-server	Configure the NTP server
	<ucast_addr>	The unicast IP address
Defaults	N/A	
Command Modes	Privileged EXEC DHCP Configuration	
Usage Guidelines	N/A	
Examples	moxa(dhcp-config)# ntp-server 192.168.127.254	
Error Messages	N/A	
Related Commands	N/A	

Remove NPT Server IP Address

Commands

no ntp-server

Syntax Description	no	Remove configuration/delete entry/reset to default value
	ntp-server	Configure the NTP server
Defaults	N/A	
Command Modes	Privileged EXEC DHCP Configuration	
Usage Guidelines	N/A	
Examples	moxa(dhcp-config)# no ntp-server	
Error Messages	N/A	
Related Commands	N/A	

Time

Time Zone

Configure Clock Time Zone

Commands

```
clock timezone { "-12" | "-11" | "-10" | "-9:30" | "-9" | "-8" | "-7" | "-6" | "-5" | "-4" | "-3:30" | "-3" | "-2" | "-1" | "0" | "1" | "2" | "3" | "3:30" | "4" | "4:30" | "5" | "5:30" | "5:45" | "6" | "6:30" | "7" | "8" | "8:30" | "8:45" | "9" | "9:30" | "10" | "10:30" | "11" | "12" | "12:45" | "13" | "14" }
```

Syntax Description	clock	Configure system clock parameters
	timezone	Configure the timezone
	"-12"	UTC-12:00
	"-11"	UTC-11:00
	"-10"	UTC-10:00
	"-9:30"	UTC-09:30
	"-9"	UTC-09:00
	"-8"	UTC-08:00
	"-7"	UTC-07:00
	"-6"	UTC-06:00
	"-5"	UTC-05:00
	"-4"	UTC-04:00
	"-3:30"	UTC-03:30
	"-3"	UTC-03:00
	"-2"	UTC-02:00
	"-1"	UTC-01:00
	"0"	UTC+00:00
	"1"	UTC+01:00
	"2"	UTC+02:00
	"3"	UTC+03:00
	"3:30"	UTC+03:30
	"4"	UTC+04:00
	"4:30"	UTC+04:30
	"5"	UTC+05:00
	"5:30"	UTC+05:30
	"5:45"	UTC+05:45
	"6"	UTC+06:00
	"6:30"	UTC+06:30
	"7"	UTC+07:00
	"8"	UTC+08:00
	"8:30"	UTC+08:30
	"8:45"	UTC+08:45
	"9"	UTC+09:00
	"9:30"	UTC+09:30
	"10"	UTC+10:00
	"10:30"	UTC+10:30
	"11"	UTC+11:00
	"12"	UTC+12:00
	"12:45"	UTC+12:45
	"13"	UTC+13:00

	"14"	UTC+14:00
Defaults	N/A	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	moxa# configure terminal moxa(config)# clock timezone "8"	
Error Messages	N/A	
Related Commands	N/A	

System Time

Configure Clock Source

Commands

clock source { local | ntp | sntp | ptp }

Syntax Description	clock	Configure system clock parameters
	source	Configure the source of the system clock
	local	Use the local clock
	ntp	Use Network Time Protocol (NTP)
	sntp	Use Simple Network Time Protocol (SNTP)
	ptp	Use Precision Time Protocol (PTP)
Defaults	clock source: local	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	moxa# configure terminal moxa(config)# clock source local	
Error Messages	N/A	
Related Commands	N/A	

Configure Clock Setting

Commands

clock set hh:mm:ss [month] [day] [year]

Syntax Description	clock	Configure system clock parameters
	set	Configure the system time
	hh:mm:ss	The system time in the format hh:mm:ss
	month	The month, January (1) to December (12)
	day	The day of the month (1 to 31)
	year	The year
Defaults	N/A	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	moxa# configure terminal moxa(config)# clock set 11:11:11 12 31 2019	
Error Messages	N/A	
Related Commands	N/A	

Enable Clock Summer Time

Commands

clock summer-time enable

Syntax Description	clock	Configure system clock parameters
	summer-time	Configure Daylight Savings Time parameters
	enable	Enable Daylight Savings Time
Defaults	Daylight saving time is disabled by default	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	moxa# configure terminal moxa(config)# clock summer-time enable	
Error Messages	Invalid: The start date plus offset should before the end date.	
Related Commands	N/A	

Disable Clock Summertime

Commands

clock summer-time disable

Syntax Description	clock	Configure system clock parameters
	summer-time	Configure Daylight Savings Time parameters
	disable	Disable Daylight Savings Time
Defaults	Daylight saving time is disabled by default	
Command Modes	Privileged EXEC Global Configuration	
Usage Guidelines	N/A	
Examples	moxa# configure terminal moxa(config)# clock summer-time disable	
Error Messages	N/A	
Related Commands	N/A	

Configure Clock Summertime Start Date

Commands

clock summer-time start-date [month] [day] [year] [hour minute hh:mm:ss]

Syntax Description	clock	Configure system clock parameters
	summer-time	Configure Daylight Savings Time parameters
	start-date	Configure the start date of Daylight Saving Time
	month	The month, January (1) to December (12)
	day	The day of the month (1 to 31)
	year	The year
	hour	The hour
	minute	The minutes
Defaults	The daylight saving time start date is set to Jan 01 2000 00:00	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	moxa# configure terminal moxa(config)# clock summer-time start-date 1 1 2019 23 30	
Error Messages	Invalid: Start date is invalid. Invalid: The start date plus offset should before the end date.	
Related Commands	N/A	

Configure Clock Summertime End Date

Commands

clock summer-time start-date month day year hour minute

Syntax Description	clock	Configure system clock parameters
	summer-time	Configure Daylight Savings Time parameters
	end-date	Configure the end date of Daylight Savings Time
	month	The month, January (1) to December (12)
	day	The day of the month (1 to 31)
	year	The year
	hour	The hour
	minute	The minutes
Defaults	The daylight saving time end date is set to Dec 31 2000 23:00	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	moxa# configure terminal moxa(config)# clock summer-time end-date 7 31 2019 23 30	
Error Messages	Invalid: End date is invalid Invalid: The start date plus offset should before the end date.	
Related Commands	N/A	

Configure Clock Summertime Offset

Commands

clock summer-time offset offset-hour [offset-minute]

Syntax Description	clock	Configure system clock parameters
	summer-time	Configure Daylight Savings Time parameters
	offset	Configure the offset of Daylight Saving Time
	offset-hour	The time offset hours
	offset-minute	The time offset minutes
Defaults	daylight saving time offset: 0 Hour 0 Minutes	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	moxa# configure terminal moxa(config)# clock summer-time offset 1 30	
Error Messages	Invalid: The start date plus offset should before the end date.	
Related Commands	N/A	

Configure NTP Authentication Key

Commands

ntp authentication-key key-index key-id md5 key-string

no ntp authentication-key key-index

Syntax Description	no ntp authentication-key key-index key-id md5 key-string	Remove configuration/delete entry/reset to default value Configure NTP/SNTP parameters Configure the NTP authentication key The index of the key, ranging from 1 to 10 The key ID, ranging from 1 to 65535 Use MD5 authentication The authentication key with a maximum length of 32 characters for plain text, 66 characters for Moxa-encrypted hex
Defaults	N/A	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	<pre>moxa# configure terminal moxa(config)# ntp authentication-key 1 1 md5 1a2b3c4d moxa(config)# no ntp authentication-key 1</pre>	
Error Messages	Invalid: Authentication key ID <i>key-id</i> is duplicated.	
Related Commands	N/A	

Configure NTP Remote Server

Commands

ntp remote-server ntp server-index server-address [authentication key key-id]

no ntp remote-server ntp server-index [authentication]

Syntax Description	no ntp remote-server ntp server-index server-address authentication key key-id	Remove configuration/delete entry/reset to default value Configure NTP/SNTP parameters Configure remote time server parameters Configure NTP server parameters The index of the server, ranging from 1 to 2 The NTP server address Configure NTP authentication parameters Use key authentication The ID of the authentication key
Defaults	NTP time server: time.nist.gov	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	<pre>moxa# configure terminal moxa(config)# ntp remote-server ntp 1 1.1.1.1 moxa(config)# ntp remote-server ntp 2 2.2.2.2 authentication key 1 moxa(config)# no ntp remote-server ntp 2 authentication moxa(config)# no ntp remote-server ntp 1</pre>	
Error Messages	Invalid: Authentication key ID <i>key-id</i> of NTP client <i>server-index</i> does not exist.	
Related Commands	N/A	

Configure SNTP Remote Server

Commands

ntp remote-server sntp server-index server-address
no ntp remote-server sntp server-index server-address

Syntax Description	no	Remove configuration/delete entry/reset to default value
	ntp	Configure NTP/SNTP parameters
	remote-server	Configure remote time server parameters
	sntp	Configure SNTP server parameters
	server-index	The index of the server, ranging from 1 to 2
	server-address	The SNTP server address
Defaults	The default SNTP time server is set to time.nist.gov	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	<pre>moxa# configure terminal moxa(config)# ntp remote-server sntp 1 1.1.1.1 moxa(config)# no ntp remote-server sntp 1</pre>	
Error Messages	N/A	
Related Commands	N/A	

Enable NTP Server

Commands

ntp server enable

Syntax Description	ntp	Configure NTP/SNTP parameters
	server	Configure NTP server parameters
	enable	Enable the NTP server
Defaults	NTP server: disable	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	<pre>moxa# configure terminal moxa(config)# ntp server enable</pre>	
Error Messages	N/A	
Related Commands	N/A	

Disable NTP Server

Commands

ntp server disable

Syntax Description	ntp	Configure NTP/SNTP parameters
	server	Configure NTP server parameters
	disable	Disable the NTP server
Defaults	The NTP server is disabled by default	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	<pre>moxa# configure terminal moxa(config)# ntp server disable</pre>	
Error Messages	N/A	
Related Commands	N/A	

Configure NTP Server Authentication

Commands

ntp server authentication

Syntax Description	ntp	Configure NTP/SNTP parameters
	server	Configure NTP server parameters
	authentication	Enable authentication
Defaults	NTP server authentication is disabled by default	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	moxa# configure terminal moxa(config)# ntp server authentication	
Error Messages	N/A	
Related Commands	N/A	

Disable NTP Server Authentication

Commands

no ntp server authentication

Syntax Description	no	Remove configuration/delete entry/reset to default value
	ntp	Configure NTP/SNTP parameters
	server	Configure NTP server parameters
	authentication	NTP authentication
Defaults	NTP server authentication is disabled by default	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	moxa# configure terminal moxa(config)# no ntp server authentication	
Error Messages	N/A	
Related Commands	N/A	

Show Clock Information

Commands

show clock

Syntax Description	show	Display the configuration/status information.
	clock	Display the system clock information.
Defaults	N/A	
Command Modes	User EXEC Privileged EXEC	
Usage Guidelines	N/A	
Examples	<pre>moxa# show clock Clock Source : Local Time Zone : UTC+00:00 Current Time : Fri May 03 22:59:33 2019 Daylight Saving : Disabled Start Date : Jan 01 2000 00:00 End Date : Dec 31 2000 23:00 Offset : 0 Minutes Authentication Keys NTP Client Time Server [1] time.nist.gov (No Auth) SNTP Client Time Server [1] time.nist.gov NTP/SNTP Server : Disabled Authentication : Disabled</pre>	
Error Messages	N/A	
Related Commands	N/A	

Port

Port Interface

Port Setting

Show Interface Status

Commands

show interface status

Syntax Description	show	Show running system information									
	interface	Display interface information									
	status	The status of the interface									
Defaults	N/A										
Command Modes	Privileged EXEC										
Usage Guidelines	N/A										
Examples	<pre>moxa# show interface status Port Status Duplex Speed Negotiation MDI/MDIX ---- ----- ----- ----- ----- ----- Eth1/1 connected Full 100 Mbps Auto MDIX(Auto) Eth1/2 not connected - - Auto - Eth1/3 not connected - - Auto - Eth1/4 not connected - - Auto - Eth1/5 not connected - - Auto - Eth1/6 not connected - - Auto - Eth1/7 not connected - - Auto - Eth1/8 not connected - - Auto - moxa#</pre>										
Error Messages	N/A										
Related Commands	N/A										

Show Interface Type and ID

Commands

show interfaces [<interface-type> <interface-id>]

show interfaces [{ [<interface-type> <interface-id>] [{ description | storm-control | status }]}]

Syntax Description	show Display configuration/statistics/general interfaces Display interface information interface-type The Ethernet type interface-id The slot number/port number description Description about the interface storm-control Broadcast, multicast, and unicast storm control suppression levels for an interface status The status of the interface
Defaults	N/A
Command Modes	Privileged EXEC
Usage Guidelines	N/A
Examples	<pre>moxa# show interfaces ethernet 1/1 Eth1 admin up, oper status is up (connected) Interface SubType: gigabitEthernet Interface Alias: Slot1 Media Type: 1000Combo. Hardware Address is 00:90:E8:11:22:32 MTU :1522 bytes Duplex: Full duplex Speed: 100 Mbps Negotiation: Auto Negotiation MDI/MDIX: MDIX(Auto) Port State: Forwarding Reception Counters Octets : 71652 Packets : 933 Unicast Packets : 504 Multicast Packets : 313 Broadcast Packets : 116 Discarded Packets : 0 CRC Errors : 0 Undersize Packets : 0 Oversize Packets : 0 Transmission Counters Octets : 59783 Packets : 866 Unicast Packets : 443 Multicast Packets : 423 Broadcast Packets : 0 moxa#</pre>
Error Messages	N/A
Related Commands	N/A

Show Interface Description

Commands

show interface description

Syntax Description	show	Display configuration/statistics/general information
	interface	Display interface information
	description	Description about the interface
Defaults	N/A	
Command Modes	Privileged EXEC	
Usage Guidelines	N/A	
Examples	<pre>moxa# show interface description Interface AdminStatus OperStatus Description ----- ----- ----- Eth1/1 up up Eth1/2 up down Eth1/3 up down Eth1/4 up down Eth1/5 up down Eth1/6 up down Eth1/7 up down Eth1/8 up down moxa#</pre>	
Error Messages	N/A	
Related Commands	N/A	

Configure Shutdown Settings

Commands

shutdown

no shutdown

Syntax Description	no	Remove configuration/delete entry/reset to default value
	shutdown	Configure shutdown parameters
Defaults	Physical ports are enabled by default	
Command Modes	Interface Configuration	
Usage Guidelines	N/A	
Examples	<pre>moxa# config moxa(config)# interface ethernet 1/1 moxa(config-if)# shutdown</pre>	
Error Messages	N/A	
Related Commands	N/A	

Configure Description Settings

Commands

description <description of this interface>

no description

Syntax Description	no	Remove configuration/delete entry/reset to default value
	description	Configure description parameters
	description of this interface	The description of the interface
Defaults	Empty string	
Command Modes	Interface Configuration	
Usage Guidelines	N/A	
Examples	moxa(config-if)# description moxa	
Error Messages	% Port Setting: Invalid: data.portTable[0].description must be shorter than or equal to 127 characters	
Related Commands	N/A	

Configure Duplex Settings

Commands

duplex { full | half }

Syntax Description	duplex	Configure duplex parameters
	full	Set the port to full-duplex mode
	half	Set the port to half-duplex mode
Defaults	The port is full-duplex without auto-negotiation by default	
Command Modes	Interface Configuration	
Usage Guidelines	If the port is a combo port, the port duplex configuration is only effective on the copper interface.	
Examples	moxa(config-if)# no auto-negotiation moxa(config-if)# duplex full	
Error Messages	% Port Setting: Invalid: Fiber port can only be configured to full duplex/auto-mdix. % Port Setting: Invalid: Speed, Duplex and MDI/MDIX can only be configured when the port exists.	
Related Commands	speed { 10 100 }	

Configure Speed Settings

Commands

speed { 10 | 100 }

Syntax Description	speed	Configure port speed parameters
	10	Set the port to run at 10 Mbps
	100	Set the port to run at 100 Mbps
Defaults	The port is set to 100 Mbps by default if auto-negotiation is disabled on the port	
Command Modes	Interface Configuration	
Usage Guidelines	If the port is a combo port, the speed configuration is only effective on the copper interface.	
Examples	moxa(config-if)# no auto-negotiation moxa(config-if)# speed 100	
Error Messages	% Port Setting: Invalid: Speed cannot configure a speed which is over the ability of the port. % Port Setting: Invalid: If a speed is equal to or faster than 10G, the port cannot configure autoNego/duplex/speed.	

	% Port Setting: Invalid: Speed, Duplex and MDI/MDIX can only be configured when the port exists.
Related Commands	duplex { full half }

Configure mdix Setting

Commands

mdix { auto | mdi | mdix }

Syntax Description	mdix	Configure MDI/MDIX parameters
	auto	Set the port as an auto-crossover port
	mdi	Set the port as an MDI port
	mdix	Set the port as an MDIX port
Defaults	Auto-crossover is enabled by default	
Command Modes	Interface Configuration	
Usage Guidelines	If the port is a combo port, the mdix configuration is only effective on the copper interface.	
Examples	moxa(config-if)# mdix auto	
Error Messages	% Port Setting: Invalid: Fiber port can only be configured to full duplex/auto-mdix. % Port Setting: Invalid: Speed, Duplex and MDI/MDIX can only be configured when the port exists.	
Related Commands	N/A	

Configure Auto-Negotiation Setting

Commands

auto-negotiation

no auto-negotiation

Syntax Description	no	Remove configuration/delete entry/reset to default value
	auto-negotiation	Configure auto-negotiation parameters
Defaults	Auto-negotiation is enabled by default	
Command Modes	Interface Configuration	
Usage Guidelines	If the port is a combo port, the auto-negotiation configuration is only effective on the copper interface.	
Examples	moxa(config-if)# auto-negotiation	
Error Messages	N/A	
Related Commands	speed { 10 100 } duplex { full half }	

Layer 2 Switching

VLAN

IEEE 802.1Q

Show VLAN Interface Status

Commands

show vlan

Syntax Description	show	Display configuration/statistics/general information
	vlan	Display the VLAN interface status
Defaults	N/A	
Command Modes	Privileged EXEC User EXEC	
Usage Guidelines	N/A	
Examples	<pre>moxa# show vlan Vlan database ----- Vlan ID : 1 Member Ports : Eth1/1, Eth1/2, Eth1/3, Eth1/4 Eth1/5, Eth1/6, Eth1/7, Eth1/8 Untagged Ports : Eth1/1, Eth1/2, Eth1/3, Eth1/4 Eth1/5, Eth1/6, Eth1/7, Eth1/8 ----- moxa#</pre>	
Error Messages	N/A	
Related Commands	vlan <vlan-id> ports add <interface-type> <1/a-b> untagged <interface-type> <1/a-b> vlan active vlan name	

Show VLAN Port Configuration

Commands

show vlan port config port [{ < interface-type > < interface-id> }]

Syntax Description	show Display configuration/statistics/general information vlan Display VLAN interface status port The port interface config The port's configuration port The port interface interface-type The Ethernet type interface-id integer The interface ID: slot number/port number
Defaults	N/A
Command Modes	Privileged EXEC User EXEC
Usage Guidelines	N/A
Examples	<pre>moxa# show vlan port config port eth 1/1 Vlan Port configuration table Port Eth1/1 Port Vlan ID: 1 Port Mode : Access moxa#</pre>
Error Messages	N/A
Related Commands	Switchport pvid Switchport acceptable-frame-type Switchport ingress-filter Switchport mode vlan restricted group restricted switchport filtering-utility-criteria

Show MAC Address Table Information

Commands

```

show mac-address-table [vlan <vlan-range>] [address <aa:aa:aa:aa:aa:aa>] [interface <interface-type> <interface-id> ]
show mac-address-table aging-time
show mac-address-table count [vlan <vlan-id>]
show mac-address-table dynamic multicast [vlan <vlan-range>] [address <aa:aa:aa:aa:aa:aa>]
[interface {<interface-type> <interface-id>}]
show mac-address-table dynamic unicast [vlan <vlan-range>] [address <aa:aa:aa:aa:aa:aa>]
[interface {<interface-type> <interface-id>}]
show mac-address-table static multicast [vlan <vlan-range>] [address <aa:aa:aa:aa:aa:aa>]
[interface {<interface-type> <interface-id>}]
show mac-address-table static unicast [vlan <vlan-range>] [address <aa:aa:aa:aa:aa:aa>] [interface
{<interface-type> <interface-id>}]
```

Syntax Description	show Display configuration/statistics/general information mac-address-table Display MAC address information address MAC address entry aging-time Maximum age of a Mac address table entry count Number of MAC addresses present on all the VLANs or on a specified VLAN dynamic Dynamic learned MAC address static Static configured MAC address multicast Multicast MAC address unicast Unicast MAC address vlan The VLAN interface vlan-range The VLAN ID range for which the details will be displayed. This value ranges from 1 to 4094. For example, 4000-4010 will show information for those VLAN IDs. interface-id The interface ID: slot number/port number integer
Defaults	N/A
Command Modes	Privileged EXEC User EXEC
Usage Guidelines	N/A
Examples	<pre>moxa# show mac-address-table vlan Mac Address Type ConnectionId Ports --- ----- 1 00:00:5e:00:01:02 Learnt 1 00:21:cc:62:f7:0b Learnt 1 00:21:cc:72:a8:d7 Learnt Total Mac Addresses displayed: 3</pre>
Error Messages	N/A
Related Commands	mac-address-table

Show MAC Address Table for Dynamic Multicast and Unicast

Commands

```
show mac-address-table dynamic multicast [vlan <vlan-range>] [address <aa:aa:aa:aa:aa:aa>]
[interface <interface-type> <interface-id> }]
show mac-address-table dynamic unicast [vlan <vlan-range>] [address <aa:aa:aa:aa:aa:aa>]
[interface <interface-type> <interface-id> ]
```

Syntax Description	show Display configuration/statistics/general information mac-address-table Display MAC address information dynamic Display dynamically learned MAC addresses multicast The multicast MAC addresses unicast The unicast MAC addresses vlan The VLAN interface vlan-range The VLAN ID range for which the details will be displayed. This value auto-negotiation ranges from 1 to 4094. For example, 4000-4010 will show information for those VLAN IDs. interface-id The slot number/port number
Defaults	N/A
Command Modes	Privileged EXEC User EXEC
Usage Guidelines	N/A
Examples	<pre>moxa# show mac-address-table dynamic unicast VLAN MAC Address Type Ports ---- ----- ---- ----- 1 00:60:6e:ba:ba:0b Learnt Eth1/1 Total Mac Addresses Displayed: 1 moxa#</pre>
Error Messages	N/A
Related Commands	mac-address-table

Show MAC Address Table for Static Multicast and Unicast

Commands

show mac-address-table static multicast [address <aa:aa:aa:aa:aa:aa>] [interface { <interface-type> <interface-id> }]
show mac-address-table static unicast [vlan <vlan-range>] [address <aa:aa:aa:aa:aa:aa>] [interface { <interface-type> <interface-id> }]

Syntax Description	show	Display configuration/statistics/general information
	mac-address-table	Display MAC address information
	static	Static entry
	multicast	The multicast MAC address
	unicast	The unicast MAC address
	vlan	The VLAN interface
	vlan-range	The VLAN ID range for which the details will be displayed. This value ranges from 1 to 4094. For example, 4000-4010 will show information for those VLAN IDs.
	interface-id	The slot number/port number
Defaults	N/A	
Command Modes	Privileged EXEC User EXEC	
Usage Guidelines	N/A	
Examples	<pre>moxa# show mac-address-table static unicast vlan 1 Vlan MAC Address Type Ports 1 00:01:02:03:04:05 Static Eth1/5 Total Mac Addresses Displayed: 1 moxa#</pre>	
Error Messages	N/A	
Related Commands	mac-address-table	

Show VLAN Management

Commands

show management vlan

Syntax Description	show	Display configuration/statistics/general information
	management	Display Management VLAN information
	vlan	The VLAN interface
Defaults	N/A	
Command Modes	Privileged EXEC User EXEC	
Usage Guidelines	N/A	
Examples	<pre>moxa# show management vlan Management VLAN 1 moxa#</pre>	
Error Messages	N/A	
Related Commands	Management vlan No management vlan	

Create/Delete a VLAN

Commands

vlan <vlan-id>

no vlan <vlan-id>

Syntax Description	vlan/no vlan	Create/delete a VLAN
	vlan-id	The VLAN identifier
Defaults	N/A	
Command Modes	Configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# vlan 100 moxa(config)# no vlan 100 moxa(config)#+	
Error Messages	N/A	
Related Commands	interface vlan <vlan-id> show vlan	

Configure VLAN Name

Commands

vlan name <vlan name string>

Syntax Description	vlan name	Configure VLAN name
	vlan name string	Configure VLAN name string, 32 characters max.
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	moxa# con moxa(config)# vlan 1 moxa(config-vlan)# vlan name test	
Error messages	N/A	
Related commands	N/E	

Configure VLAN Mode Member Ports

Commands

```

ports add {member ([<iftype> <iface_list>]) | untagged ([<iftype> <iface_list>])}
vlan ports set member ([<iftype> <iface_list>]) [untagged ([<iftype> <iface_list>])
vlan ports add {member | untagged} [<interface-type> <slot/port-port,slot/port,...>]
no ports [<interface-type> <slot/port-port,slot/port,...>] [untagged ([<interface-type> <slot/port-
port,slot/port,...>])

```

Syntax Description	ports/no ports Set/delete member/untagged add Add member/untag set Overwrite member/untagged slot/port-port The slot number/port number interface-type The Ethernet type member Configure the ports to be set as a member of the VLAN untagged Configure the ports that will be used by the VLAN to transmit egress traffic as untagged packets.
Defaults	N/A
Command Modes	Config VLAN mode
Usage Guidelines	This command can only be executed from within VLAN configuration mode. From Configuration mode, enter vlan <vlan-id> to enter VLAN config mode.
Examples	<pre> moxa# config moxa(config)# interface ethernet 1/3 moxa(config-if)# switchport mode trunk moxa(config-if)# exit moxa(config)# vlan10 moxa(config-vlan)#ports add member ethernet 1/3 tagged all moxa(config-vlan)#ports add member ethernet 1/3 tagged ethernet 1/3 </pre>
Error Messages	N/A
Related Commands	vlan active switchport mode show vlan show mac-address-table count

Configure a Static Unicast MAC Address in the Forwarding Database

Commands

mac-address-table static unicast <aa:aa:aa:aa:aa:aa> vlan <vlan-id> set [interface ([<interface-type> <slot/port-port,slot/port,...>] [<interface-type> <slot/port-port,slot/port,...>])]
no mac-address-table static unicast <aa:aa:aa:aa:aa:aa> vlan <vlan-id>

Syntax Description	mac-address-table Configure mac-address-table parameters static The statically configured MAC address unicast Configure the unicast MAC address aa:aa:aa:aa:aa:aa The unicast MAC address vlan Configure the VLAN vlan-id The VLAN id set Set the unicast MAC address to a specified port interface-id The slot number/port number
Defaults	N/A
Command Modes	Configuration
Usage Guidelines	N/A
Examples	moxa(config)# mac-address-table static unicast 00:11:22:33:22:11 vlan 1 set interface ethernet 1/2
Error Messages	N/A
Related Commands	mac-address-table static multicast vlan vlan ports add show mac-address-table static unicast

Configure MAC Address Table Aging Time

Commands

mac-address-table aging-time <10-300 seconds>
no mac-address-table aging-time

Syntax Description	no Remove configuration/delete entry/reset to default value mac-address-table Configure the MAC-address-table aging-time Maximum age of an entry in the MAC address table to its default value. second The aging time ranging from 10 to 300 seconds
Defaults	300s
Command Modes	Configuration
Usage Guidelines	N/A
Examples	moxa(config)# mac-address-table aging-time 100
Error Messages	N/A
Related Commands	show mac-address-table aging-time

Configure PVID on a Specified Port

Commands

switchport pvid <vlan-id>
no switchport pvid

Syntax Description	no Remove configuration/delete entry/reset to default value pvid Configure port-based VLAN parameters vlan-id The VLAN ID, ranging from 1 to 4094.
Defaults	1
Command Modes	Configuration
Usage Guidelines	<p>If a PVID does not exist for this system, it will be created automatically after configuration.</p> <p>If the port is configured to be in Access Mode, the actions below will be applied automatically.</p> <ol style="list-style-type: none"> 1. Remove this port from member port list if it is bound to another VID which is different from PVID 2. Modify this port into an untagged member of this PVID <p>If the port is configured to be in Trunk Mode, the port will automatically be modified into a tagged member of this PVID.</p>
Examples	moxa(config-if)# switchport pvid 1
Error Messages	N/A
Related Commands	switchport

Configure Switch Port Operation Mode

Commands

switchport mode {access | trunk}

Syntax Description	switchport Configure the switch port mode Configure switch port mode parameters
	access Configure the port as an access port that accepts and sends only untagged packets. This kind of port is added as a member to a specific VLAN and only carries traffic for the VLAN to which the port is assigned. The port can only be set as an access port if the following 4 conditions are met: <ol style="list-style-type: none"> 1. The acceptable frame type is set as "Admit untagged and pri-tagged". 2. The port is not a tagged member of any VLAN. 3. The PVID is the same as the only untagged VLAN it joined.
	trunk Configures the port as trunk port that accepts and sends only tagged frames. This kind of port is added as members of several existing VLANs, and carries traffic for all of them. The port can only be set as a trunk port. if the following 2 conditions are met: <ol style="list-style-type: none"> 1. The acceptable frame type is set as "Admit tagged only" 2. The port is not an untagged member of any VLAN.
Defaults	The default port operation mode is set to Access
Command Modes	Configuration
Usage Guidelines	<p>When changing from trunk to access mode, the following changes will be automatically applied:</p> <p>Forces the port to become an untagged member of the PVID domain</p> <p>If the port exists in another VLAN, it will be removed</p> <p>Forces the accept frame type to be set to "Admit untagged and pri-tagged"</p>

	<p>When changing from access to trunk mode, the following changes will be automatically applied:</p> <p>Forces the port to become a tagged member of the PVID domain</p> <p>If the port was an untagged member in another VLAN, it will change into a tagged member.</p> <p>Forces the accept frame type to be set to "Admit tagged only"</p>
Examples	moxa (config-if)# switchport mode access
Error Messages	N/A
Related Commands	switchport vlan ports switchport acceptable-frame-type show vlan port config

Set VLAN Access Port

Commands

switchport access vlan <vlan-id>

Syntax Description	switchport access vlan <vlan-id>	Configure the port as an access port The specified VLAN ID for which this access port will carry traffic, ranging from 1 to 4094.
Defaults	The port mode is set to access port by default	
Command Modes	Privileged EXEC User EXEC	
Usage Guidelines	Discarding the current operation mode of the port, this command will change the port to access mode and the following changes will automatically apply: Forces the acceptable frame type to be set to "untagged AND priority tagged" Sets PVID to specified a VLAN Changes the port into an untagged member of a specified VLAN and removes this port from any other VLANs. Sets the port mode to access mode	
Examples	moxa(config-if)# switchport access vlan 10	
Error Messages	N/A	
Related Commands	show vlan port config show vlan	

Configure VLAN Management

Commands

management vlan <vlan-id>

no management vlan <vlan>

Syntax Description	no	Remove configuration/delete entry/reset to default value
	management	Configure management
	vlan	Configure the management VLAN
	vlan-id	The management VLAN ID
Defaults	The default management VLAN ID is set to 1	
Command Modes	Privileged EXEC User EXEC	
Usage Guidelines	N/A	
Examples	moxa(config)# management vlan 1	
Error Messages	N/A	
Related Commands	N/A	

MAC

Static Unicast

Configure a Static Unicast MAC Address in the Forwarding Database

Commands

```
mac-address-table static unicast <aa:aa:aa:aa:aa:aa> vlan <vlan-id> set [interface ([<interface-type>
<slot/port-port,slot/port,...>] [<interface-type> <slot/port-port,slot/port,...>] [status { permanent }])]
no mac-address-table static unicast <aa:aa:aa:aa:aa:aa> vlan <vlan-id>
```

Syntax Description	no Remove configuration/delete entry/reset to default value mac-address-table Configure MAC address table parameters static Statically configured MAC address unicast The unicast MAC address set Overwrite port interface-id The slot number/port number status Specify the status of the static unicast entry: permanent - entry remains even after the next reset of the bridge
Defaults	N/A
Command Modes	Privileged EXEC/User EXEC
Usage Guidelines	N/A
Examples	moxa(config)# mac-address-table static unicast aa:aa:aa:bb:bb:cc vlan 168 set interface ethernet 2/4 status permanent
Error Messages	N/A
Related Commands	mac-address-table static multicast vlan vlan ports add show mac-address-table static unicast

MAC Address Table

Show MAC Address Table Information

Commands

```

show mac-address-table [vlan <vlan-range>] [address <aa:aa:aa:aa:aa:aa>] [interface <interface-type> <interface-id> ]
show mac-address-table aging-time
show mac-address-table count [vlan <vlan-id>]
show mac-address-table dynamic multicast [vlan <vlan-range>] [address <aa:aa:aa:aa:aa:aa>]
<interface-type> <interface-id> }
show mac-address-table dynamic unicast [vlan <vlan-range>] [address <aa:aa:aa:aa:aa:aa>]
<interface-type> <interface-id> }
show mac-address-table static multicast [vlan <vlan-range>] [address <aa:aa:aa:aa:aa:aa>]
<interface-type> <interface-id> }
show mac-address-table static unicast [vlan <vlan-range>] [address <aa:aa:aa:aa:aa:aa>]
<interface-type> <interface-id> ]

```

Syntax Description	mac-address-table Display MAC address information address The MAC address entry aging-time The maximum age of a MAC address table entry count The number of MAC addresses present on all VLANs or on a specified VLAN dynamic Dynamically learned MAC address static Statically configured MAC address multicast The multicast MAC address unicast The unicast MAC address vlan The VLAN interface vlan-range The VLAN ID range for which the details will be displayed. This value ranges from 1 to 4094. For example, 4000-4010 will show information for those VLAN IDs. interface-id The slot number/port number
Defaults	N/A
Command Modes	Privileged EXEC/User EXEC
Usage Guidelines	N/A
Examples	<pre> moxa# show mac-address-table vlan Mac Address Type ConnectionId Ports --- ----- --- ----- 1 00:00:5e:00:01:02 Learnt Eth1/3 1 00:21:cc:62:f7:0b Learnt Eth1/3 1 00:21:cc:72:a8:d7 Learnt Eth1/3 Total Mac Addresses displayed: 3 </pre>
Error Messages	N/A
Related Commands	mac-address-table

Multicast

Static Multicast

Show MAC Address Table for Static Multicast

Commands

```
show mac-address-table static multicast [vlan <vlan-range>] [address <aa:aa:aa:aa:aa:aa>] |<interface-type> <interface-id>]
```

Syntax Description	mac-address-table Display the MAC address table information static multicast Display static multicast address information vlan <vlan-range> Display all entries in the FDB table for the specified VLANs address <aa:aa:aa:aa:aa:aa> Display the specified multicast MAC address in the FDB table
Defaults	N/A
Command Modes	Privileged EXEC User EXEC
Usage Guidelines	Display static multicast address table
Examples	<pre>moxa# show mac-address-table static multicast Static Multicast Table ----- Vlan : 1 Mac Address : 01:02:03:04:05:06 Member Ports : Eth1/1 Status : Permanent ----- Total Mac Addresses displayed: 1</pre>
Error Messages	N/A
Related Commands	mac-address-table static multicast

Configure MAC Address Table for Static Multicast

Commands

mac-address-table static multicast <aa:aa:aa:aa:aa:aa> vlan <vlan-id> {add | set} interface [<interface-type> <slot/port-port,slot/port,...>] [status permanent]

Syntax Description	mac-address-table Configure the MAC address table static multicast Configure the static multicast address aa:aa:aa:aa:aa:aa The multicast destination MAC address vlan <vlan-id> The VLAN ID of the VLAN the multicast destination MAC address belongs to add Add the new interface port Set Overwrite the new interface port interface Configure member ports details. status The status of the static multicast entry. permanent Entry remains even after the next reset of the bridge
Defaults	N/A
Command Modes	Privileged EXEC Global Configuration
Usage Guidelines	Configure the static multicast address
Examples	moxa(config)# mac-address-table static multicast 01:02:03:04:05:06 vlan 1 add interface ethernet 1/1-2
Error Messages	"Invalid: Duplicate MAC Address." "Invalid: Configuration fail." "Invalid: The port is not included in VLAN egress ports." "Invalid: The MAC+VID entry must be removed from Port Security first." "Invalid: The port must remove from port security." "Invalid: Reserved multicast address (01:80:C2) is not allowed to set static multicast."
Related Commands	show mac-address-table static multicast

Network Redundancy

Layer 2 Redundancy

Spanning Tree

Configure Spanning Tree Compatibility

Commands

spanning-tree compatibility { stp | rstp }

no spanning-tree compatibility

Syntax Description	no spanning-tree compatibility stp rstp	Disable the configuration/delete the entry/resets to default value Configure Spanning Tree Protocol parameters The Spanning Tree compatibility version Spanning Tree Protocol configuration Rapid Spanning Tree configuration
Defaults	Spanning Tree Protocol compatibility is set to rstp by default.	
Command Modes	Global Configuration	
Usage Guidelines	The "no spanning-tree compatibility" command will restore the default value	
Examples	<pre>moxa# configure terminal moxa(config)# spanning-tree compatibility stp moxa(config)# spanning-tree compatibility rstp moxa(config)# no spanning-tree compatibility</pre>	
Error Messages	N/A	
Related Commands	show spanning-tree show spanning-tree detail	

Configure Spanning Tree Priority

Commands

spanning-tree priority <value (0-61440)>

no spanning-tree priority

Syntax Description	no spanning-tree priority value	Disable the configuration / deletes the entry / resets to default value Configure Spanning Tree Protocol parameters Configure switch priority for Spanning Tree instances The switch priority value ranging from 0 to 61440
Defaults	The default priority is set to 32768	
Command Modes	Global Configuration	
Usage Guidelines	The "no spanning-tree priority" command will restore the default value	
Examples	<pre>moxa# configure terminal moxa(config)# spanning-tree priority 61440 moxa(config)# no spanning-tree priority</pre>	
Error Messages	N/A	
Related Commands	show spanning-tree show spanning-tree detail	

Configure Spanning Tree Forward Time

Commands

spanning-tree forward-time <seconds (4-30)>

no spanning-tree forward-time

Syntax Description	no	Disable the configuration/deletes the entry/resets to default value
	spanning-tree	Configure Spanning Tree Protocol parameters
	forward-time	The interval (in seconds) in which a port stays in its current state before moving to next state
	seconds	The forwarding time ranging from 4 to 30 seconds
Defaults	The default forwarding time is 15 seconds	
Command Modes	Global Configuration	
Usage Guidelines	Command "no spanning-tree forward-time" will reset to default value $2*(ForwardDelay - 1) \geq MaxAge \geq 2*(Hello Time + 1)$	
Examples	<pre>moxa# configure terminal moxa(config)# spanning-tree forward-time 16 moxa(config)# no spanning-tree forward-time</pre>	
Error Messages	% RSTP: $2*(Forward time - 1) \geq Max age time \geq 2*(Hello time + 1)$	
Related Commands	show spanning-tree show spanning-tree detail	

Configure Spanning Tree Hello Time

Commands

spanning-tree hello-time <seconds (1-2)>

no spanning-tree hello-time

Syntax Description	no	Disable the configuration/deletes the entry/resets to default value
	spanning-tree	Configure Spanning Tree Protocol parameters
	hello-time	The interval (in seconds) between the transmission of configuration BPDUs
	seconds	The hello time interval ranging from 1 to 2 seconds
Defaults	The default hello time is set to 2 seconds	
Command Modes	Global Configuration	
Usage Guidelines	The "no spanning-tree hello-time" command will restore the default value $2*(ForwardDelay - 1) \geq MaxAge \geq 2*(Hello Time + 1)$	
Examples	<pre>moxa# configure terminal moxa(config)# spanning-tree hello-time 1 moxa(config)# no spanning-tree hello-time</pre>	
Error Messages	% RSTP: $2*(Forward time - 1) \geq Max age time \geq 2*(Hello time + 1)$	
Related Commands	show spanning-tree show spanning-tree detail	

Configure Spanning Tree Maximum Age

Commands

spanning-tree max-age <seconds (6-40)>

no spanning-tree max-age

Syntax Description	no Disable the configuration/delete the entry/reset to default value spanning-tree Configure Spanning Tree Protocol parameters max-age The maximum age (in seconds) before learnt STP information is discarded seconds The maximum age ranging from 6 to 40 seconds
Defaults	The STP maximum age is set to 20 seconds by default
Command Modes	Global Configuration
Usage Guidelines	The “no spanning-tree max-age” command will restore the default value $2*(ForwardDelay - 1) \geq MaxAge \geq 2*(Hello Time + 1)$
Examples	<pre>moxa# configure terminal moxa(config)# spanning-tree max-age 21 moxa(config)# no spanning-tree max-age</pre>
Error Messages	% RSTP: $2*(Forward time - 1) \geq Max age time \geq 2*(Hello time + 1)$
Related Commands	show spanning-tree show spanning-tree detail

Configure Spanning Tree Transmission Hold Counter

Commands

spanning-tree transmit hold-count <value (1-10)>

no spanning-tree transmit hold-count

Syntax Description	no Disable the configuration/delete the entry/reset to default value spanning-tree Configure Spanning Tree Protocol transmit Transmission hold counter configuration hold-count Configure the hold counter to limit the maximum transmission rate of the switch value The transmission hold counter value ranging from 1 to 10
Defaults	The STP hold counter is set to 6 by default
Command Modes	Global Configuration
Usage Guidelines	The “no spanning-tree transmit hold-count” command will restore the default value
Examples	<pre>moxa# configure terminal moxa(config)# spanning-tree transmit hold-count 10 moxa(config)# no spanning-tree transmit hold-count</pre>
Error Messages	N/A
Related Commands	show spanning-tree detail

Configure Spanning Tree Auto-edge

Commands

spanning-tree auto-edge

no spanning-tree auto-edge

Syntax Description	no Disable the configuration/delete the entry/reset to default value spanning-tree Configure Spanning Tree Protocol auto-edge Configure the automatic detection of bridges attached to an interface
Defaults	Spanning Tree auto-edge is enabled by default
Command Modes	Interface Configuration
Usage Guidelines	N/A
Examples	<pre>moxa# configure terminal moxa(config)# interface ethernet 1/1 moxa(config-if)# spanning-tree auto-edge moxa(config-if)# no spanning-tree auto-edge</pre>
Error Messages	N/A
Related Commands	show spanning-tree detail show spanning-tree interface ethernet 1/1 detail

Configure Spanning Tree Cost

Commands

spanning-tree cost <value (0-200000000)>

no spanning-tree cost

Syntax Description	no Disable the configuration/delete the entry/reset to default value spanning-tree Configure Spanning Tree Protocol cost Configure the path cost value The Spanning Tree cost ranging from 0 to 200000000
Defaults	The default path cost is set to 0
Command Modes	Interface Configuration
Usage Guidelines	The "spanning-tree cost 0" command will auto-detect the cost based on port speed The "no spanning-tree cost" command will restore the default value
Examples	<pre>moxa# configure terminal moxa(config)# interface ethernet 1/1 moxa(config-if)# spanning-tree cost 20000 moxa(config-if)# no spanning-tree cost</pre>
Error Messages	N/A
Related Commands	show spanning-tree detail show spanning-tree interface ethernet 1/1 detail show spanning-tree interface ethernet 1/1 detail

Configure Spanning Tree Link Type

Commands

spanning-tree link-type { point-to-point | shared }

no spanning-tree link-type

Syntax Description	no	Disable the configuration/delete the entry/reset to default value
	spanning-tree	Configure Spanning Tree Protocol parameters
	link-type	Configure the link type as a point-to-point link or as a shared LAN segment on which another bridge is present
	point-to-point	Set the link to a point-to-point link
	shared	Set the link as a shared link
Defaults	The default Spanning Tree link-type is set to auto-detect	
Command Modes	Interface Configuration	
Usage Guidelines	The “no spanning-tree link-type” command will auto-detect the interface link type based on the port duplex mode	
Examples	<pre>moxa# configure terminal moxa(config)# interface ethernet 1/1 moxa(config-if)# spanning-tree link-type point-to-point moxa(config-if)# spanning-tree link-type shared moxa(config-if)# no spanning-tree link-type</pre>	
Error Messages	N/A	
Related Commands	show spanning-tree detail show spanning-tree interface ethernet 1/1 show spanning-tree interface ethernet 1/1 detail	

Configure Spanning Tree Portfast

Commands

spanning-tree portfast

no spanning-tree portfast

Syntax Description	no	Disable the configuration/delete the entry/reset to default value
	spanning-tree	Configure Spanning Tree Protocol parameters
	portfast	Specify ports that have only hosts connected to enable immediate transition to a forwarding state
Defaults	Spanning Tree Portfast is disabled by default	
Command Modes	Interface Configuration	
Usage Guidelines	Shut down the interface before enabling the Portfast function The Portfast function cannot be enabled on a port that has loop guard enabled	
Examples	<pre>moxa# configure terminal moxa(config)# interface ethernet 1/1 moxa(config-if)# spanning-tree portfast moxa(config-if)# no spanning-tree portfast</pre>	
Error Messages	N/A	
Related Commands	show spanning-tree detail show spanning-tree interface ethernet 1/1 show spanning-tree interface ethernet 1/1 detail	

Configure Spanning Tree Port Priority

Commands

spanning-tree port-priority <value (0-240)>

no spanning-tree port-priority

Syntax Description	no Disable the configuration/delete the entry/reset to default value spanning-tree Configure Spanning Tree Protocol parameters port-priority Configure the port priority value value The Spanning Tree port priority ranging from 0 to 240
Defaults	The default Spanning Tree port priority is set to 128
Command Modes	Interface Configuration
Usage Guidelines	The “no spanning-tree port-priority” command will restore the default value
Examples	<pre>moxa# configure terminal moxa(config)# interface ethernet 1/1 moxa(config-if)# spanning-tree port-priority 16 moxa(config-if)# no spanning-tree port-priority</pre>
Error Messages	N/A
Related Commands	show spanning-tree detail show spanning-tree interface ethernet 1/1 show spanning-tree interface ethernet 1/1 detail

Clear Spanning Tree Detected Protocols

Commands

clear spanning-tree detected protocols interface { <interface-id> }

Syntax Description	clear	Clear the configuration
	spanning-tree	Configure Spanning Tree Protocol parameters
	detected	Spanning Tree detected protocols
	protocols	Spanning Tree detected protocols
	interface	Configure the interface
	interface-id	The interface ID
Defaults	N/A	
Command Modes	User EXEC mode	
Usage Guidelines	N/A	
Examples	moxa# clear spanning-tree detected protocols interface ethernet 1/1	
Error Messages	N/A	
Related Commands	N/A	

Show Spanning Tree Bridge Information

Commands

show spanning-tree bridge

Syntax Description	show	Display the Configuration/statistics/general information															
	spanning-tree	Spanning Tree-related information															
	bridge	Spanning Tree bridge information															
Defaults	N/A																
Command Modes	User EXEC Mode																
Usage Guidelines	N/A																
Examples	<pre>moxa# show spanning-tree bridge</pre> <table> <thead> <tr> <th>Bridge ID</th> <th>HelloTime</th> <th>MaxAge</th> <th>FwdDly</th> <th>Protocol</th> </tr> </thead> <tbody> <tr> <td>-----</td> <td>-----</td> <td>-----</td> <td>-----</td> <td>-----</td> </tr> <tr> <td>80:00:00:01:02:03:04:05</td> <td>2 sec</td> <td>20 sec</td> <td>15 sec</td> <td>rstp</td> </tr> </tbody> </table> <pre>moxa#</pre>		Bridge ID	HelloTime	MaxAge	FwdDly	Protocol	-----	-----	-----	-----	-----	80:00:00:01:02:03:04:05	2 sec	20 sec	15 sec	rstp
Bridge ID	HelloTime	MaxAge	FwdDly	Protocol													
-----	-----	-----	-----	-----													
80:00:00:01:02:03:04:05	2 sec	20 sec	15 sec	rstp													
Error Messages	N/A																
Related Commands	N/A																

Show Spanning Tree Root Information

Commands

show spanning-tree root

Syntax Description	show	Display the configuration/statistics/general information															
	spanning-tree	Spanning Tree-related information															
	root	Spanning Tree root information															
Defaults	N/A																
Command Modes	User EXEC Mode																
Usage Guidelines	N/A																
Examples	<pre>moxa# show spanning-tree root</pre> <table> <thead> <tr> <th>Root ID</th> <th>RootCost</th> <th>MaxAge</th> <th>FwdDly</th> <th>RootPort</th> </tr> </thead> <tbody> <tr> <td>-----</td> <td>-----</td> <td>-----</td> <td>-----</td> <td>-----</td> </tr> <tr> <td>00:00:00:00:00:00:00</td> <td>0 sec</td> <td>20 sec</td> <td>15 sec</td> <td>0</td> </tr> </tbody> </table> <pre>moxa#</pre>		Root ID	RootCost	MaxAge	FwdDly	RootPort	-----	-----	-----	-----	-----	00:00:00:00:00:00:00	0 sec	20 sec	15 sec	0
Root ID	RootCost	MaxAge	FwdDly	RootPort													
-----	-----	-----	-----	-----													
00:00:00:00:00:00:00	0 sec	20 sec	15 sec	0													
Error Messages	N/A																
Related Commands	N/A																

Show Spanning Tree Interface Information

Commands

show spanning-tree interface { ethernet <slot/port> }

show spanning-tree interface { ethernet <slot/port> } detail

Syntax Description	show	Display the configuration/statistics/general information															
	spanning-tree	Spanning Tree-related information															
	interface	Spanning Tree interface information															
	ethernet <slot/port>	The Ethernet slot or port number															
	detail	Detailed information about the port and bridge															
Defaults	N/A																
Command Modes	User EXEC Mode																
Usage Guidelines	N/A																
Examples	<pre>moxa# show spanning-tree interface ethernet 1/2 moxa# show span in eth 1/1</pre> <table> <thead> <tr> <th>Root</th> <th>State</th> <th>Cost</th> <th>Prio</th> <th>Type</th> </tr> </thead> <tbody> <tr> <td>-----</td> <td>----</td> <td>---</td> <td>----</td> <td>----</td> </tr> <tr> <td>Disabled</td> <td>Disable</td> <td>200000000</td> <td>128</td> <td>SharedLAN</td> </tr> </tbody> </table> <pre>moxa#</pre>		Root	State	Cost	Prio	Type	-----	----	---	----	----	Disabled	Disable	200000000	128	SharedLAN
Root	State	Cost	Prio	Type													
-----	----	---	----	----													
Disabled	Disable	200000000	128	SharedLAN													
Error Messages	N/A																
Related Commands	N/A																

Show Spanning Tree Details

Commands

show spanning-tree [detail]

Syntax Description	show	Display the configuration/statistics/general information									
	spanning-tree	Spanning Tree related information									
	detail	Detailed Spanning Tree information									
Defaults	N/A										
Command Modes	User EXEC Mode										
Usage Guidelines	N/A										
Examples	<pre>moxa# show spanning-tree Root Id Priority 0 Address 00:00:00:00:00:00 Cost 0 Port 0 Max Age 20 sec Forward Delay 15 sec Hello Time 2 sec Spanning tree Protocol has been disabled Bridge Id Priority 32768 Address 00:90:E8:11:22:31 Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec Port Role State Cost Prio Type ---- ---- ---- ---- ---- ---- Eth1/1 Disabled Discarding 20000 128 SharedLan Eth1/2 Disabled Discarding 20000 128 SharedLan Eth1/3 Disabled Discarding 20000 128 SharedLan Eth1/4 Disabled Discarding 20000 128 SharedLan Eth1/5 Disabled Discarding 20000 128 SharedLan Eth1/6 Disabled Discarding 20000 128 SharedLan Eth1/7 Disabled Discarding 20000 128 SharedLan Eth1/8 Disabled Discarding 20000 128 SharedLan moxa#</pre>										
Error Messages	N/A										
Related Commands	N/A										

Management

Network Management

SNMP

Show SNMP Server Information

Commands

show snmp-server information

Syntax Description	show	Display the configuration/statistics/general information
	snmp-server	Display SNMP server information
	information	Display general SNMP server information
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	<pre>moxa# show snmp-server information ----- snmp-server : enable ----- version : v1-v2c community read-only : public community read-write : private</pre>	
Error Messages	% Can't get snmp-server information % Can't get snmp-server community information	
Related Commands	snmp-server	

Show SNMP Server User Account Information

Commands

show snmp-server user

Syntax Description	show	Displays the configuration/statistics/general information
	snmp-server	Displays SNMP server information
	user	Displays SNMP server user accounts
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	<pre>moxa# show snmp-server user ----- snmp-server user-account : 3 ----- user-name : testNoAuthNoPriv authority : read_write authenticate-type : none encryption-method : disable user-name : testAuthNoPriv authority : read_write authenticate-type : md5 encryption-method : disable user-name : testAuthPriv authority : read_write authenticate-type : md5 encryption-method : des</pre>	
Error Messages	<pre>% Can't get snmp-server user-account information % Can't get snmp-server user-account table</pre>	
Related Commands	snmp-server	

Show SNMP Server Engine ID Information

Commands

show snmp-server engine-id

Syntax Description	show	Display the configuration/statistics/general information
	snmp-server	Display SNMP server information
	engine-id	Display the engine ID of the SNMP server
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	<pre>moxa# show snmp-server engine-id snmp-server engineID : 800021f303000111234567</pre>	
Error Messages	<pre>% Can't get snmp-server status information</pre>	
Related Commands	snmp-server	

Configure SNMP Server Access Mode

Commands

snmp-server access { enable | disable | read-only }

Syntax Description	snmp-server Configure SNMP server parameters access Configure the SNMP server access mode enable Enable SNMP server access disable Disable SNMP server access read-only Set SNMP server access to read-only mode
Defaults	SNMP server access is enabled by default
Command Modes	Global configuration
Usage Guidelines	N/A
Examples	moxa(config)# snmp-server access enable moxa(config)# snmp-server access disable moxa(config)# snmp-server access read-only
Error Messages	N/A
Related Commands	snmp-server show snmp-server

Configure SNMP Server Read-Only Community Settings

Commands

snmp-server community read-only <community-name(32)>

Syntax Description	snmp-server Configure snmp-server related parameters community Configure the SNMP server community read-only Configure the SNMP server community for read-only string (32) The SNMP server read-only community name
Defaults	The default read-only community name is set to public
Command Modes	Global configuration
Usage Guidelines	N/A
Examples	moxa(config)# snmp-server community read-only public
Error Messages	N/A
Related Commands	snmp-server show snmp-server

Delete SNMP Server Read-Only Community

Commands

no snmp-server community read-only

Syntax Description	no	Disable the configuration/delete the entry/reset to default value
	snmp-server	Configure SNMP server parameters
	community	Configure the SNMP server community
	read-only	Configure the SNMP server community for read-only
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# no snmp-server community read-only	
Error Messages	N/A	
Related Commands	snmp-server show snmp-server	

Configure SNMP Server Read-Write Community Settings

Commands

snmp-server community read-write <community-name(32)>

Syntax Description	snmp-server	Configure SNMP server parameters
	community	Configure the SNMP server community
	read-write	Configure the SNMP server community for read-write
	community-name	Configure the community name of the SNMP server
	string (32)	The SNMP server read-write community name
Defaults	The default read-write community name is set to private	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# snmp-server community read-write private	
Error Messages	N/A	
Related Commands	snmp-server show snmp-server	

Configure SNMP Server Read-Write Community to Default Value

Commands

no snmp-server community read-write

Syntax Description	no	Disable the configuration/delete the entry /reset to default value
	snmp-server	Configures SNMP server parameters
	community	Configure the SNMP server community
	read-write	Configure the SNMP server community for read-write
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# no snmp-server community read-write	
Error Messages	N/A	
Related Commands	snmp-server show snmp-server	

Configure SNMP Server Version

Commands

snmp-server version { v1-v2c-v3 | v1-v2c | v3 }

Syntax Description	snmp-server	Configure SNMP server parameters
	version	Configure the SNMP server version compatibility
	v1-v2c-v3	Set the SNMP server version to v1-v2c-v3
	v1-v2c	Set the SNMP server version to v1-v2c
	v3	Set the SNMP server version to v3-only
Defaults	The default SNMP server version is set to v1-v2c	
Command Modes	Global configuration	
Usage Guidelines	Set up at least one SNMP server user account before enabling v1-v2c-v3 or v3	
Examples	<pre>moxa(config)# snmp-server version v1-v2c-v3 moxa(config)# snmp-server version v1-v2c moxa(config)# snmp-server version v3</pre>	
Error Messages	% Atleast setup one valid user before enable snmp-server version v1-v2c-v3 or v3	
Related Commands	snmp-server show snmp-server	

Configure SNMP Server Version to Default Value

Commands

no snmp-server version

Syntax Description	no	Disable the configuration/delete the entry/reset to default value
	snmp-server	Configure SNMP server parameters
	version	Configure the SNMP server version compatibility
Defaults	The default SNMP server version is set to v1-v2c	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# no snmp-server version	
Error Messages	N/A	
Related Commands	snmp-server show snmp-server	

Configure SNMP Server User Account Settings

Commands

```
snmp-server user <user-name(32)>
authority { read-only | read-write }
auth-type { none | md5 | sha } [auth-passwd <authentication-password(64)> ] encryption { disable| des
| aes } [encryption-key <encryption-key(64)>]
```

Syntax Description	snmp-server	Configure SNMP server parameters
	user	Configure SNMP server user accounts
	user-name (32)	The user name of the SNMP server user account
	authority	Configure the access right for the user account
	read-only	Give read-only access to the user
	read-write	Give read-write access to the user
	auth-type	Configure the authentication protocol for the SNMP server user account
	none	Do not use any authentication protocol
	md5	Use MD5 authentication
	sha	Use SHA authentication
	auth-passwd	Configure the authentication password for the SNMP server user account
	authentication-password (64)	The authentication password
	encryption	Configure the data encryption protocol for the SNMP server user account
	disable	Disable data encryption
	des	Use DES data encryption
	aes	Use AES data encryption
	encryption-key	Configure the data encryption key for the SNMP server user account
	encryption-key (64)	The data encryption key
Defaults	There is no user account table by default	
Command Modes	Global configuration	
Usage Guidelines	If the authentication type is set to none, data encryption should be disabled. If the authentication type is not none, an authentication password must be set up. If data encryption is not disabled, a data encryption key must be set up.	
Examples	<pre>moxa(config)# snmp-server user testNoAuthNoPriv authority read-write auth-type none encryption disable moxa(config)# moxa(config)# moxa(config)# snmp-server user testAuthNoPriv authority read-write auth-type md5 auth-passwd 1111111111 encryption disable moxa(config)# moxa(config)# moxa(config)# snmp-server user testAuthPriv authority read-write auth-type md5 auth-passwd 1111111111 encryption des encryption-key 2222222222 moxa(config)# moxa(config)# </pre>	
Error Messages	% If authentication-type is none, data-encryption method should be disabled % must setup authentication password % must setup data encryption key % Can't get snmp-server user-account information % Can't get snmp-server user-account table % Can't get snmp-server user-account table index ('%d') % Can't get user-name from snmp-server user-account table('%d')	

	% Can't create user account % Can't modify user account
Related Commands	snmp-server show snmp-server

Delete SNMP Server User Account

Commands

no snmp-server user <user-name (32)>

Syntax Description	no Disable the configuration/delete the entry/reset to default value snmp-server Configure SNMP server parameters user Configure SNMP server user accounts user-name (32) The user name of the SNMP server user account
Defaults	N/A
Command Modes	Global configuration
Usage Guidelines	N/A
Examples	<pre>moxa(config)# no snmp-server user testNoAuthNoPriv moxa(config)# no snmp-server user testAuthNoPriv moxa(config)# no snmp-server user testAuthPriv</pre>
Error Messages	% Can't get snmp-server user-account information % Can't get snmp-server user-account table % Can't get snmp-server user-account table index ('%d') % Can't get user-name from snmp-server user-account % Can't delete user account
Related Commands	snmp-server show snmp-server

Configure SNMP Server Transport Protocol Mode

Commands

snmp-server transport-protocol { udp | tcp }

Syntax Description	snmp-server Configure SNMP server parameters transport-protocol transport-protocol Transport layer protocol udp udp User datagram protocol tcp tcp Transmission control protocol
Defaults	udp
Command Modes	Global configuration
Usage Guidelines	N/A
Examples	<pre>moxa# config moxa(config)# snmp-server transport-protocol udp moxa(config)# snmp-server transport-protocol tcp</pre>
Error messages	N/A
Related commands	snmp-server show snmp-server

SNMP Trap/Inform

Show SNMP Trap Information

Commands

show snmp-trap information

Syntax Description	show	Display the configuration/statistics/general information
	snmp-trap	Display SNMP trap information
	information	Display general SNMP trap information
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	<pre>moxa# show snmp-trap information ----- snmp-trap : ----- inform-retry : 3 inform-timeout : 10</pre>	
Error Messages	% Can't get snmp-trap information	
Related Commands	snmp-trap	

Show SNMP Trap User Account Information

Commands

show snmp-trap user

Syntax Description	show	Display the configuration/statistics/general information
	snmp-trap	Display SNMP trap information
	user	Display SNMP trap user accounts
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	<pre>moxa# show snmp-trap user ----- snmp-trap user-account : 1 ----- user-name : testNoAuthNoPriv authenticate-type : none encryption-method : disable</pre>	
Error Messages	% Can't get snmp-trap user-account information % Can't get snmp-trap user-account table % Can't get snmp-trap user-account table index ('%d')	
Related Commands	snmp-trap	

Show SNMP Trap Host Information

Commands

show snmp-trap host

Syntax Description	show Display the configuration/statistics/general information snmp-trap Display SNMP trap information host Display SNMP trap host information
Defaults	N/A
Command Modes	Global configuration
Usage Guidelines	N/A
Examples	<pre>moxa# show snmp-trap host ----- snmp-trap host-table : 2 ----- hostName : 192.168.137.254 mode : trap-v1 community : public hostName : 192.168.127.253 mode : inform-v3 community :</pre>
Error Messages	% Can't get snmp-trap host information % Can't get snmp-trap host table % Can't get snmp-trap host table index('%d')
Related Commands	snmp-trap

Configure SNMP Trap Host Settings

Commands

snmp-trap host <host-address(32)> mode { trap-v1 | trap-v2c | inform-v2c | trap-v3 | inform-v3 }
[community <community-name(32)>]

Syntax Description	snmp-trap Configure SNMP trap parameters host Configure the SNMP trap host address host-address (32) The SNMP trap host address mode Configure the SNMP trap mode trap-v1 Use trap-v1 mode trap-v2c Use trap-v2c mode inform-v2c Use inform-v2c mode trap-v3 Use trap-v3 mode inform-v3 Use inform-v3 mode community Configure the community for the SNMP trap host community-name (32) The community name for the SNMP trap host
Defaults	There is no SNMP trap host entry by default
Command Modes	Global configuration
Usage Guidelines	A community name must be set when using trap-v1, trap-v2c, or inform-v2c mode. SNMP v3 must be enabled when SNMP trap-v3 mode is enabled. At least one valid user must be set up before setting the SNMP trap host to trap-v3 mode.
Examples	<pre>moxa(config)# snmp-trap host 192.168.127.254 mode trap-v1 community public moxa(config)# snmp-trap host 192.168.127.253 mode inform-v3</pre>
Error Messages	% Can't get snmp-trap host information % Can't get host name from snmp-trap host table

	% Can't get snmp-trap host table index('%d') % Can't get host-name from snmp-trap host table('%d') % Can't create host entry % Can't modify host entry % must set community name when mode is trap-v1, trap-v2c or inform-v2c % must enable v3 in snmp-server when snmp-trap host <host-address> trap-v3 mode is enable % Atleast setup one valid user before enable snmp-trap host to trap-v3 mode
Related Commands	snmp-trap show snmp-trap

Delete SNMP Trap Host Entry

Commands

no snmp-trap host <host-address(32)>

Syntax Description	no	Disable the configuration/delete the entry/reset to default value
	snmp-trap	Configure SNMP trap parameters
	host	Configure the SNMP trap host address
	host-address (32)	The SNMP trap host address
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# no snmp-trap host 192.168.127.254 moxa(config)# no snmp-trap host 192.168.127.253	
Error Messages	% Can't get snmp-trap host information % Can't get host name from snmp-trap host table % Can't get snmp-trap host table index('%d') % Can't get host-name from snmp-trap host table('%d') % Can't delete host entry	
Related Commands	snmp-trap show snmp-trap	

Configure SNMP Trap Inform Retry Setting

Commands

snmp-trap inform-retries <inform-retries-number(1-99)>

Syntax Description	snmp-trap	Configure SNMP trap parameters
	inform-retries	Configure SNMP trap inform retries
	inform-retries-number (1-99)	The amount of SNMP trap inform retries
Defaults	The default number of SNMP trap inform retries is set to 3	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# snmp-trap inform-retries 3	
Error Messages	N/A	
Related Commands	snmp-trap show snmp-trap	

Reset SNMP Trap Inform Retry to Default Value

Commands

no snmp-trap inform-retries

Syntax Description	no	Disable the configuration/delete the entry/reset to default value
	snmp-trap	Configure SNMP trap parameters
	inform-retries	Configure SNMP trap inform retries
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# no snmp-trap inform-retries	
Error Messages	N/A	
Related Commands	snmp-trap show snmp-trap	

Configure SNMP Trap Inform Timeout Setting

Commands

snmp-trap inform-timeout <inform-timeout-number(1-300)>

Syntax Description	snmp-trap	Configure SNMP trap parameters
	inform-timeout	Configure the SNMP trap inform timeout
	inform-timeout-number (1-300)	The SNMP trap inform timeout in seconds
Defaults	The default SNMP trap inform timeout is set to 10 seconds	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# snmp-trap inform-timeout 10	
Error Messages	N/A	
Related Commands	snmp-trap show snmp-trap	

Reset SNMP Trap Inform Timeout to Default Value

Commands

no snmp-trap inform-timeout

Syntax Description	no	Disable the configuration/delete the entry/reset to default value
	snmp-trap	Configure SNMP trap parameters
	inform-timeout	Configure the SNMP trap inform timeout
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# no snmp-trap inform-timeout	
Error Messages	N/A	
Related Commands	snmp-trap show snmp-trap	

Configure SNMP Trap User Account Settings

Commands

snmp-trap user <user-name(32)> auth-type { none | md5 | sha } [auth-passwd <authentication-password(64)>] encryption { disable| des | aes } [encryption-key <encryption-key(64)>]

Syntax Description	snmp-trap user user-name(32) auth-type none md5 sha auth-passwd authentication-password (64) encryption disable des aes encryption-key encryption-key (64)	Configures SNMP trap parameters Configure SNMP trap user accounts The user name of the SNMP trap user account Configure the authentication protocol for the SNMP trap user account Do not use any authentication protocol Use MD5 authentication Use SHA authentication Configure the authentication password for the SNMP trap user account The authentication password Configure the data encryption protocol for the SNMP trap user account Disable data encryption Use DES data encryption Use AES data encryption Configure the data encryption key for the SNMP trap user account The data encryption key
Defaults	There is no user account table by default	
Command Modes	Global configuration	
Usage Guidelines	If the authentication type is set to none, data encryption should be disabled. If the authentication type is not none, an authentication password must be set up. If data encryption is not disabled, a data encryption key must be set up.	
Examples	<pre>moxa# config moxa(config)# snmp-trap user test auth-type none encryption disable moxa(config)# snmp-trap user test auth-type md5 auth-passwd 1111111111 encryption disable moxa(config)# snmp-trap user test auth-type md5 auth-passwd 1111111111 encryption des encryption-key 2222222222</pre>	
Error Messages	% If authentication-type is none, data-encryption method should be disabled % must setup authentication password % must setup data encryption key % Can't get snmp-trap user-account information % Can't get snmp-trap user-account table % Can't get snmp-trap user-account table index ('%d') % Can't get user-name from snmp-trap user-account table('%d') % Can't create user account % Can't modify user account	
Related Commands	snmp-trap show snmp-trap	

Delete SNMP Trap User Account

Commands

no snmp-trap user <user-name (32)>

Syntax Description	no	Disable the configuration/delete the entry/reset to default value
	snmp-trap	Configures SNMP trap parameters
	user	Configure SNMP trap user accounts
	user-name (32)	The user name of the SNMP trap user account
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# no snmp-trap user test	
Error Messages	% Can't get snmp-trap user-account information % Can't get snmp-trap user-account table % Can't get snmp-trap user-account table index ('%d') % Can't get user-name from snmp-trap user-account % Can't delete user account	
Related Commands	snmp-trap show snmp-trap	

Security

Device Security

Management Interface

Enable Network Server

Commands

ip { http | https | telnet | ssh | moxa-command } server enable

Syntax Description	ip Configure IP parameters http Configure HTTP management UI service parameters https Configure HTTPS management UI service parameters telnet Configure Telnet management UI service parameters ssh Configure SSH management UI service parameters moxa-command Configure Moxa Command management UI service parameters server Configure management UI service server parameters enable Enable the management UI service
Defaults	http: enabled https: enabled telnet: enabled ssh: enabled moxa-command: enabled
Command Modes	Global Configuration
Usage Guidelines	N/A
Examples	<pre>moxa# configure terminal moxa(config)# ip https server enable</pre>
Error Messages	N/A
Related Commands	N/A

Disable Network Server

Commands

ip { http | https | telnet | ssh | moxa-command } server disable

Syntax Description	ip Configure IP parameters http Configure HTTP management UI service parameters https Configure HTTPS management UI service parameters telnet Configure Telnet management UI service parameters ssh Configure SSH management UI service parameters moxa-command Configure Moxa Command management UI service parameters server Configure management UI service server parameters disable Disable the management UI service
Defaults	http: enabled https: enabled telnet: enabled ssh: enabled moxa-command: enabled
Command Modes	Global Configuration
Usage Guidelines	N/A
Examples	moxa# configure terminal moxa(config)# ip telnet server disable
Error Messages	N/A
Related Commands	N/A

Configure Network Port Numbers

Commands

ip { http | https | telnet | ssh } port <port-number>

Syntax Description	ip Configure IP parameters http Configure HTTP management UI service parameters https Configure HTTPS management UI service parameters telnet Configure Telnet management UI service parameters ssh Configure SSH management UI service parameters port Configure the service port of the management UI service port-number The service port number
Defaults	http server port: 80 https server port: 443 telnet server port: 23 ssh server port: 22
Command Modes	Global Configuration
Usage Guidelines	N/A
Examples	moxa# configure terminal moxa(config)# ip http port 8080
Error Messages	Invalid: UI service management port <i>port-number</i> is duplicated.
Related Commands	N/A

Configure SNMP Server Port Number

Commands

snmp-server port <port-number>

Syntax Description	snmp-server	Configure SNMP server parameters
	port	Configure the service port of the SNMP server
	port-number	The service port number
Defaults		The default SNMP server port is set to 161
Command Modes		Global Configuration
Usage Guidelines		N/A
Examples		moxa# configure terminal moxa(config)# snmp-server port 1661
Error Messages		N/A
Related Commands		N/A

Configure Network Maximum Session Numbers

Commands

ip http max-session <session-number>

Syntax Description	ip	Configure IP parameters
	http	Configure HTTP/HTTPS management UI service parameters
	max-session	Configure the maximum number of concurrent login sessions through HTTP and HTTPS
	session-number	The maximum number of login sessions
Defaults		The maximum number of concurrent HTTP sessions is set to 5 by default
Command Modes		Global Configuration
Usage Guidelines		N/A
Examples		moxa# configure terminal moxa(config)# ip http max-session 3
Error Messages		N/A
Related Commands		N/A

Configure Network Terminal Maximum Session Numbers

Commands

ip terminal max-session <session-number>

Syntax Description	ip	Configure IP parameters
	terminal	Configure Telnet and SSH terminal parameters
	max-session	Configure the maximum number of concurrent login sessions through Telnet and SSH terminal
	session-number	Maximum number of login sessions
Defaults		max terminal session: 1
Command Modes		Global Configuration
Usage Guidelines		N/A
Examples		moxa# configure terminal moxa(config)# ip terminal max-session 3
Error Messages		N/A
Related Commands		N/A

Show Network Service Information

Commands

show ip service information

Syntax Description	show Display configuration/status information ip Display IP information service Display management UI service information information Display the information for management UI services
Defaults	N/A
Command Modes	User EXEC Privileged EXEC
Usage Guidelines	N/A
Examples	<pre>moxa# show ip service information HTTP service: Enabled HTTP port: 80 HTTPS service: Enabled HTTPS port: 443 Telnet service: Enabled Telnet port: 23 SSH service: Enabled SSH port: 22 SNMP service: Enabled SNMP port: 161 MOXA service: Enabled HTTP/HTTPS Maximum Login Sessions: 5 Telnet/SSH Maximum Login Sessions: 1</pre>
Error Messages	N/A
Related Commands	N/A

Login Policy

Configure Login Lockout Settings

Commands

login lockout <enable|disable>

login lockout <minute(1-10)> **attempts <tries(1-10)>**

Syntax Description	login Configure login parameters lockout Configure the maximum number of failed login attempts and the lockout time to block the user from logging in enable Enable login lockout disable Disable login lockout minute Configure the lockout time ranging from 1 to 10 minutes attempts Configure the maximum number of login attempts tries The number of tries ranging from 1 to 10
Defaults	N/A
Command Modes	Global configuration
Usage Guidelines	N/A
Examples	<pre>(config)# login lockout 10 attempts 5 (config)# login lockout enable (config)# login lockout disable</pre>
Error messages	N/A
Related commands	N/A

Configure Login Banner

Commands

login banner <string (500)>

no login banner

Syntax Description	no	Remove configuration/delete entry/reset to default value
	login	Configure login parameters
	banner	Configure a login banner
	string	The login banner content up to 500 characters
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	(config)# login banner "this is a banner" (config)# no login banner	
Error messages	N/A	
Related commands	N/A	

Configure Login Failure Message

Commands

login fail-message <string (500)>

no login fail-message

Syntax Description	no	Remove configuration/delete entry/reset to default value
	login	Configure login parameters
	fail-message	Configure a login failure message
	string	The login failure message up to 500 characters
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	(config)# login fail-message "this is a failure message" (config)# no login fail-message	
Error messages	N/A	
Related commands	N/A	

Configure Timeout Value for a Session End

Commands

session timeout <integer (0-1440)>

Syntax Description	session	Configure session parameters
	timeout	Configure the session timeout value
	integer	The timeout value ranging from 0 to 1440 seconds
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	moxa# config moxa(config)# session timeout 100	
Error messages	N/A	
Related commands	N/A	

Show Session Timeout Information

Commands

show session timeout

Syntax Description	show	Display running information
	session	Display session information
	timeout	Display session timeout information
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	moxa# show session timeout Session TimeOut: 5 (Min)	
Error messages	N/A	
Related commands	N/A	

Show Login Failure Message

Commands

show login fail-message

Syntax Description	show	Display running information
	login	Display login information
	fail-message	Display the login failure message
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	moxa# show log fail-message Login Fail Message: This is a failed message!	
Error messages	N/A	
Related commands	N/A	

Show Login Banner

Commands

show login banner

Syntax Description	show	Display running information
	login	Display login information
	banner	Display the login banner
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	moxa# show log banner Login Banner Message: this is a banner	
Error messages	N/A	
Related commands	N/A	

Show Login Authentication

Commands

show login authentication

Syntax Description	show	Display running information
	login	Display login information
	authentication	Display authentication information
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	moxa# show login authentication Login Authentication Method: Local	
Error messages	N/A	
Related commands	N/A	

Trusted Access

Configure Trusted Access Settings

Commands

trusted-access ip-source <ucast_addr> [{ <ip_mask> | "/" <short(0-32)> }]
no trusted-access <ucast_addr> [{ <ip_mask> | "/" <short(0-32)> }]

Syntax Description	no	Disable the configuration/delete the entry/reset to default value
	trusted-access	Configure IP trusted access parameters
	ip-source	Configure the IP source
	ucast_addr	Configure the network or host IP address
	ip_mask	Configure the subnet mask of the IP address
	"/"	Configure the CIDR notation
	short (0-32)	Configure the prefix length
Defaults	Trusted access is disabled by default	
Command Modes	Privileged EXEC Global Configuration	
Usage Guidelines	Trusted access will take effect when the "trusted-access enable" command is executed.	
Examples	(config)# trusted-access ip-source 10.10.10.10 255.255.255.0 (config)# trusted-access ip-source 20.10.10.10 / 24 (config)# trusted-access ip-source 30.10.10.10 (config)# no trusted-access ip-source 10.10.10.10 255.255.255.0 (config)# no trusted-access ip-source 20.10.10.10 / 24 (config)# no trusted-access ip-source 30.10.10.10	
Error Messages	N/A	
Related Commands	show trusted-access trusted-access enable	

Enable/Disable IP Trusted Access List

Commands

trusted-access <enable>
trusted-access <disable>

Syntax Description	trusted-access	Configure IP trusted access parameters
	enable	Enable the IP trusted access list
	disable	Disable the IP trusted access list
Defaults	N/A	
Command Modes	Privileged EXEC Global Configuration	
Usage Guidelines	N/A	
Examples	(config)# trusted-access enable (config)# trusted-access disable	
Error messages	N/A	
Related commands	trusted-access disable	

Show Trusted Access IP List

Commands

show trusted-access

Syntax Description	show	Display configuration/status information
	trusted-access	Display IP trusted access information
Defaults	N/A	
Command Modes	User EXEC Privileged EXEC	
Usage Guidelines	N/A	
Examples	moxa# show trusted-access Trusted Access Table : Disabled ----- IP Address : 210.222.222.225 Subnet Mask : 255.255.255.0 moxa#	
Error Messages	% No such manager found % Manager is not configured	
Related Commands	trusted-access	

SSH & SSL

Re-generate New Web SSL Certificate

Commands

web certificate generate

Syntax Description	web	Configure web parameters
	certificate	Configure the web server certificate
	generate	Generate a self-signed certificate
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	(config)# web certificate generate	
Error messages	N/A	
Related commands	N/A	

Import New Web SSL Certificate via TFTP or SFTP

Commands

web certificate import {<tftp_url> | <sftp_url>}

Syntax Description	web	Configure web parameters
	certificate	Configure the web server certificate
	import	Import the certificate from a remote server
	tftp_url	The file on the remote TFTP server to be copied
	sftp_url	The file on the remote SFTP server to be copied
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	(config)# web certificate import tftp://192.168.1.1/server.crt	
Error messages	Format or Password Error Server not Connected	
Related commands	N/A	

Export Web SSL Certificate Signing Request via TFTP/SFTP

Commands

web signing-request export {<tftp_url> | <sftp_url>}

Syntax Description	web	Configure Web related parameters
	signing-request	Configure the web server certificate signing request
	export	Export the certificate
	tftp_url	The file on the remote TFTP server to be copied
	sftp_url	The file on the remote SFTP server to be copied
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	(config)# web signing-request export tftp://192.168.1.1/server.csr	
Error Messages	Server not Connected	
Related Commands	N/A	

Re-generate New SSH Key

Commands

ssh key generate

Syntax Description	ssh	Configure SSH parameters
	key	Configure the SSH server key
	generate	Generate the SSH key
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	(config)# ssh key generate	
Error messages	N/A	
Related commands	N/A	

Network Security

Traffic Storm Control

Enable/Disable Storm Control

Commands

storm-control { bc | mc | bc_mc } level <rate-value(1000-1488000)>

no storm-control {bc | mc | bc_mc }

Syntax Description	no	Remove configuration delete entry/reset to default value
	storm-control	Configure storm control parameters
	bc	Configure broadcast packet storm control parameters
	mc	Configure multicast packet storm control parameters
	bc_mc	Configure broadcast and multicast packet storm control parameters
	level	Configure the control suppression level
	rate-value	The storm control rate value
	1000-1488000	
Defaults	N/A	
Command Modes	Privileged EXEC Global Configuration	
Usage Guidelines	N/A	
Examples	<pre>moxa# configure moxa(config)# interface ethernet 1/1 moxa(config-if)# storm-control bc level 1000 moxa# configure moxa(config)# interface ethernet 1/1 moxa(config-if)# storm-control bc_mc level 2000 moxa# configure moxa(config)# interface ethernet 1/1 moxa(config-if)# no storm-control bc</pre>	
Error Messages	'Invalid: The value of traffic storm control should be less than ingress rate limit threshold.'	

	'Invalid: Your configure value {}'.format(cfg_val) + ' exists too large bias because of limitation of hardware.' + ' We suggest configure the value {} again.'.format(suggest_cfg_val)
Related Commands	moxa(config-if)# no storm-control {bc mc bc_mc } moxa# show [<ifXtype> <ifnum>] storm-control

Show Storm Control Status

Commands

show storm control interface [<ifXtype> <ifnum>]

Syntax Description	show Display configuration/status information interface Display interface information ifXtype The interface type ifnum The interface number storm-control Display the broadcast, multicast, and unicast storm control suppression levels of the interface
Defaults	N/A
Command Modes	Privileged EXEC Global Configuration
Usage Guidelines	N/A
Examples	<pre>moxa# show storm-control interface ethernet 1/1 Storm control configuration Port Idx: 1 Broadcast Storm Control : Enabled Broadcast Storm Control Level : 13000 Multicast Storm Control : Disabled moxa#</pre>
Error Messages	N/A
Related Commands	moxa(config-if)# storm-control {bc mc bc_mc } level <rate-value(625-1488100)> moxa(config-if)# no storm-control {bc mc bc_mc }

Authentication

Login Authentication

Configure Login Authentication Settings

Commands

login authentication [{ radius | tacacs }] [local]

Syntax Description	login Configure login parameters authentication Configure authentication parameters radius Configure RADIUS authentication servers tacacs Configure a TACACS authentication system local Configure a local authentication database
Defaults	N/A
Command Modes	Global configuration
Usage Guidelines	N/A
Examples	(config)# login authentication radius (config)# login authentication tacacs (config)# login authentication local (config)# login authentication radius local (config)# login authentication tacacs local
Error messages	N/A
Related commands	N/A

RADIUS

Configure RADIUS Server Host Settings

Commands

radius-server host { <ucast_addr> } [auth-port {<integer(1-65535)>}] [timeout {<short(5-180)>}] [retransmit {<short(0-5)>}] key {<string(60)>} authtype { pap | chap | mschap } { primary | secondary }
no radius-server { primary | secondary }

Syntax Description	no Disable the configuration/delete the entry/reset to default value radius-server Configure RADIUS server parameters host Configure the RADIUS host auth-port Configures the UDP destination port for authentication requests timeout Configure time period (in seconds) until which a client waits for a response from the server before re-transmitting the request retransmit Configure the maximum number of attempts the client undertakes to contact the server key Configure the RADIUS server encryption key authtype Configure the authentication type of the RADIUS server primary Set as the primary server secondary Set as the secondary server
Defaults	N/A
Command Modes	Global configuration
Usage Guidelines	N/A
Examples	(config)# radius-server host 1.1.1.1 auth-port 2222 timeout 5 retransmit 5 key test authtype pap primary (config)# no radius-server primary
Error Messages	N/A

Related Commands	N/A
------------------	-----

Show RADIUS Server Information

Commands

show radius-server

Syntax Description	show	Display running information
	radius- server	Display the RADIUS server parameters
Defaults	N/A	
Command Modes	Privileged EXEC / User EXEC	
Usage Guidelines	N/A	
Examples	moxa# show radius-server	
Error messages	N/A	
Related commands	N/A	

TACACS+

Configure TACACS+ Server Host Settings

Commands

```
tacacs-server host { <ucast_addr> } [auth-port {<integer(1-65535)>}] [timeout {<short(5-180)>} ] [retransmit {<short(0-5)>}] key {<string(60)>} authtype { pap | chap | mschap } { primary | secondary }
no tacacs-server { primary | secondary }
```

Syntax Description	no	Disable the configuration/delete the entry/reset to default value
	tacacs -server	Configure TACACS server parameters
	host	Configure TACACS host parameters
	auth-port	Configure authentication port parameters
	timeout	Configure timeout parameters
	retransmit	Configure the maximum number of attempts the client undertakes to contact the server
	key	Configure the per-server encryption key
	authtype	Configure the authentication type of the TACACS server
	primary	Set as the primary server
	secondary	Set as the secondary server
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	(config)# tacacs-server host 1.1.1.1 auth-port 2222 timeout 5 retransmit 5 key test authtype pap primary (config)# no tacacs-server primary	
Error Messages	N/A	
Related Commands	N/A	

Show TACACS+ Server Information

Commands

show tacacs server

Syntax Description	show	Displays running information
	tacacs-server	Displays the TACACS server parameters
Defaults	N/A	
Command Modes	Privileged EXEC / User EXEC	
Usage Guidelines	N/A	
Examples	moxa# show tacacs-server	
Error messages	N/A	
Related commands	N/A	

Diagnostics

System Status

Utilization

Show Device Current Information

Commands

show env {all | power | RAM | CPU }

Syntax Description	show	Display the statistics information
	env	Display switch information
	all	Show the current information for all resources such as CPU, RAM, and power
	power	Show the current power input information
	RAM	Show the current RAM information
	CPU	Show the current CPU information
Defaults	N/A	
Command Modes	Global configuration / User EXEC	
Usage Guidelines	N/A	
Examples	moxa# show env all moxa# show env power moxa# show env RAM moxa# show env CPU	
Error Messages	N/A	
Related Commands	N/A	

Statistics

Show Traffic Statistics

Commands

show statistics [interface <interface-type> <interface-id>]

Syntax Description	show	Display configuration/status information
	statistics	Display the interface statistics table
	interface-type	Display interface information
	interface-id	Display the specific interface information
Defaults	N/A	
Command Modes	Privileged EXEC Mode.	
Usage Guidelines	N/A	
Examples	moxa# show statistics interface ethernet 1/1	
Error Messages	N/A	
Related Commands	clear statistics	

Clear Traffic Statistics

Commands

clear statistics [interface <interface-type> <interface-id>]

Syntax Description	clear	Clear input
	statistics	Clear statistics
	interface-type	The interface type
	interface-id	The interface ID
Defaults	N/A	
Command Modes	Privileged EXEC Mode.	
Usage Guidelines	N/A	
Examples	moxa# config moxa(config)# clear statistics interface ethernet 1/1	
Error messages	N/A	
Related commands	show statistics	

Event Notification

Show Event Notification

Commands

show event-notification {general-event | port-event | switching-event}

Syntax Description	show Displays running information for the feature event-notification Display event-notification configuration general-event general event config port-event port event config switching-event switching event config
Defaults	N/A
Command Modes	Privileged EXEC /User EXEC
Usage Guidelines	N/A
Examples	<pre>moxa# show event-notification port-event Port link up Event Enable :Enabled Registered Action :Trap, Email, Registered Port :1/1, 1/2, 1/3, 1/4, 1/5, 1/6, 1/7, 1/8, Port Link down Event Enable :Enabled Registered Action :Trap, Email, Registered Port :1/1, 1/2, 1/3, 1/4, 1/5, 1/6, 1/7, 1/8,</pre>
Error Messages	N/A
Related Commands	event-notification general-event event-notification port-event event-notification switching-event

Configure Event Notification Settings

Commands

```

event-notification general-event all
event-notification general-event cold-start
event-notification general-event all action trap email relay
event-notification general-event cold-start action trap email relay
no event-notification general-event all

```

Syntax Description	no	Disable the configuration/deletes the entry/reset to default value
	event-notification	Configure event notifications
	general-event	Configure notifications for general events
	all	Notify for all general events
	cold-start	Notify when the system performs a cold start
	warm-start	Notify when the system performs a warm start
	config-change	Notify when the system configuration changes
	login-success	Notify when a user successfully logs in
	login-fail	Notify when a user failed to log in
	login-lockout	Notify when a user is locked out due to the login policy
	account-setting-changed	Notify when the user account information changes, including create account, remove account, and change of username, permission
	password-changed	Notify when the user account password changes
	config-import	Notify when the system configuration is imported
	ssl-certificated-changed	Notify when system certification changes
	log-capacity	Notify when the system log reaches the capacity threshold
	power-on	Notify when the power supply is on
	power-off	Notify when the power supply is off
	di-on	Notify when the digital input is on
	di-off	Notify when the digital input is off
	action	Set action for event notification
	trap	Set trap action for notification
	email	Set email action for notification
	relay	Set relay action for notification
Defaults	All configuration, trap, email event notifications are enabled by default	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	<pre> moxa# config moxa(config)# event-notification general-event all action trap email relay moxa(config)# no event-notification general-event all action trap email relay </pre>	
Error Messages	N/A	
Related Commands	show event-notification event-notification port-event event-notification switching-event	

Configure Notification for Switching Event Settings

Commands

```
event-notification switching-event all
event-notification switching-event all action trap email relay
event-notification switching-event pd-power-on action trap email relay
no event-notification switching -event all
```

Syntax Description	no	Disable the configuration/deletes the entry/resets to default value
	event-notification	Configure event notifications
	switching-event	Configure notifications for switching events
	all	Notify for all switching events
	topology-changed	Notify when the network topology changes
	rstp-topology-changed	Notify when the RSTP network topology changes
	lldp-table-changed	Notify when the LLDP remote table changes
	action	Set action for event notification
	trap	Set trap action for notification
	email	Set email action for notification
	relay	Set relay action for notification
Defaults	All configuration, trap, email event notifications are enabled by default	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	<pre>moxa# config moxa(config)# event-notification switching-event all action trap moxa(config)# no event-notification switching-event all action trap email</pre>	
Error Messages	N/A	
Related Commands	show event-notification event-notification general-event event-notification port-event	

Relay Alarm Cut-off

Configure Relay Alarm Cut-off Settings

Commands

```
relay alarm cut-off relay
```

Syntax Description	relay	Configure relay parameters
	alarm	Configure the relay alarm
	cut-off	Configure the relay alarm cut-off
	relay	Cut off the relay alarm
Defaults	N/A	
Command Modes	Global	
Usage Guidelines	N/A	
Examples	moxa# relay alarm cut-off relay	
Error Messages	N/A	
Related Commands	N/A	

Email Notification

Configure Email Notification Server

Command

email-notification server server-address <ucast_addr> [server-port <integer(1-65535)>] username <string(60)> password <string(60)>

Syntax Description	email-notification	Configure email notification parameters
	server	Configure server parameters
	server-address	Configure the email notification server IP address
	server-port	Configure the email-notification server port
	username	Configure the email notification server username
	password	Configure the email notification server password
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	(config)# email-notification server-address 1.2.3.4 username aaa password bbb	
Error messages	N/A	
Related commands	N/A	

Configure Email Notification Sender

Commands

email-notification sender <string (60)>

Syntax Description	email-notification	Configure email notification parameters
	sender	Configure the email notification sender's email address
	string (60)	The sender's email address up to 60 characters
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	(config)# email-notification sender testuser@test.com	
Error messages	Invalid Email Format	
Related commands	N/A	

Configure Email Notification Server TLS Mode Setting

Commands

email-notification server tls {enable | disable}

Syntax Description	email-notification	Configure email notification parameters
	server	Configure server parameters
	tls	Configure the email notification server TLS mode
	enable	Enable the TLS mode
	disable	Disable the TLS mode
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	(config)# mail-server server tls enable (config)# mail-server server tls disable	
Error messages	N/A	
Related commands	N/A	

Configure Email Notification Receiver

Commands

email-notification receiver <string (60)> index <integer (1-5)>

no email-notification receiver index <integer (1-5)>

Syntax Description	no	Disable the configuration/delete the entry/reset to default value
	email-notification	Configure email notification parameters
	receiver	Configure the email notification receiver
	index	Configure the index of the receiver
	string (60)	The receiver's name up to 60 characters
	integer (1-5)	The number index of the receiver ranging from 1 to 5
Defaults	N/A	
Command Modes	Global configuration	
Usage Guidelines	N/A	
Examples	(config)# email-notification receiver testuser@test.com index 1 (config)# no email-notification receiver index 1	
Error Messages	Invalid Email Format	
Related Commands	N/A	

Show Email Notification Server

Commands

show email-notification server

Syntax Description	show	Display the configuration/statistics/general information
	email-notification	Display email notification parameters
	server	Display server parameters
Defaults	N/A	
Command Modes	Privileged EXEC / User EXEC	
Usage Guidelines	N/A	
Examples	# show email-notification server	
Error Messages	N/A	
Related Commands	N/A	

Syslog

Configure Logging Server

Commands

logging-server <short(1-3)> { ipv4 <ucast_addr> | <dns_host_name> } [port <integer(1-65535)>]

Syntax Description	logging-server	Configure logging server parameters
	short (1-3)	The index of the syslog server
	ipv4	Configure IPv4 parameters
	ucast_addr	The IP address
	dns_host_name	The host domain name
	port	Configure port parameters
	integer (1-65535)	The port number
Defaults	N/A	
Command Modes	Privileged EXEC Global Configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# logging-server 1 ipv4 10.128.1.8 port 514	
Error Messages	'Invalid: The server addresses are duplicated.' 'Invalid: The syslog server address cannot be empty if it is enabled.'	
Related Commands	no logging-server <short(1-3)> show logging server	

Delete Logging Server

Commands

no logging-server <short(1-3)> [enable]

Syntax Description	no	Remove configuration / delete entry / reset to default value
	logging-server	Configure logging server parameters
	short (1-3)	The index of the syslog server
	enable	Disable this server entry
Defaults	N/A	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# no logging-server 1	
Error Messages	N/A	
Related Commands	logging-server <short(1-3)> {ipv4 <ucast_addr> <dns_host_name>} [port <integer(1-65535)>] show logging syslog-server	

Enable/Disable Logging Syslog Server

Commands

logging syslog-server { enable | disable }

Syntax Description	logging	Configure logging parameters
	syslog-server	Configure the syslog server
	enable	Enable the syslog server
	disable	Disable the syslog server
Defaults	N/A	
Command Modes	Global Configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# logging syslog-server { enable disable }	
Error Messages	'Invalid: The server addresses are duplicated.' 'Invalid: The syslog server address cannot be empty if it is enabled.'	
Related Commands	show logging server	

Show Syslog Server Configuration

Commands

show logging syslog-server

Syntax Description	show	Display configuration/status information																
	logging	Display logging information																
	syslog-server	Display syslog server information																
Defaults	N/A																	
Command Modes	Privileged EXEC / User EXEC																	
Examples	moxa# show logging syslog-server Syslog Server Configuration Syslog Enable: disable <table> <thead> <tr> <th>Index</th> <th>Server Address</th> <th>Port</th> <th>Status</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>111.2.21.1</td> <td>514</td> <td>enable</td> </tr> <tr> <td>2</td> <td>200.2.2.2</td> <td>2540</td> <td>enable</td> </tr> <tr> <td>3</td> <td></td> <td></td> <td>disable</td> </tr> </tbody> </table>		Index	Server Address	Port	Status	1	111.2.21.1	514	enable	2	200.2.2.2	2540	enable	3			disable
Index	Server Address	Port	Status															
1	111.2.21.1	514	enable															
2	200.2.2.2	2540	enable															
3			disable															
Help Message	Display the Syslog logging server table																	
Error Messages	N/A																	
Related Commands	logging server enable logging-server <short(1-3)> {ipv4 <ucast_addr> <dns_host_name>} [port <integer(1-65535)>]																	

Diagnosis

LLDP

Show LLDP Information

Commands

show lldp

Syntax Description	show	Display configuration/statistics/general information
	lldp	Display global LLDP information
Defaults	N/A	
Command Modes	Privileged EXEC User EXEC	
Usage Guidelines	Display the global LLDP settings	
Examples	<pre>moxa# show lldp LLDP status : Enabled Transmit Interval : 30 Holdtime Multiplier : 4 Chassis Id SubType : MAC Address Chassis Id : 00:90:e8:11:22:31 System Name : moxa System Desc : TSN-G5008-2GTXSFP</pre>	
Error Messages	N/A	
Related Commands	<pre>config lldp {enable disable} config lldp holdtime-multiplier <2-10> config lldp transmit-interval <seconds(5-32768)></pre>	

Show LLDP Neighbors

Commands

show lldp neighbors

Syntax Description	show	Display configuration/statistics/general information
	lldp	Display the LLDP interface status
	neighbors	Display the LLDP remote interface database
Defaults	N/A	
Command Modes	Privileged EXEC User EXEC	
Usage Guidelines	Display LLDP neighbor interface information	
Examples	<pre>moxa# show lldp neighbors Chassis Local Port ID Intf Id ----- ----- 00:60:6e:ba:ba:0b Eth1/1 00:60:6e:ba:ba:0b Total Entries Displayed : 1</pre>	
Error Messages	N/A	

Show LLDP Traffic

Commands

show lldp traffic

Syntax Description	show	Display configuration/statistics/general information
	lldp	Display the LLDP interface status
	traffic	Display the LLDP local traffic
Defaults	N/A	
Command Modes	Privileged EXEC User EXEC	
Usage Guidelines	Display LLDP traffic for the local counter	
Examples	<pre>moxa# show lldp traffic Ethernet 1/1 Total Frames Out : 125 Total Entries Aged : 0 Total Frames In : 6 Total Frames Received In Error : 0 Total Frames Discarded : 0 Total TLVS Unrecognized : 1 Ethernet 1/2 Total Frames Out : 0 Total Entries Aged : 0 Total Frames In : 0 Total Frames Received In Error : 0 Total Frames Discarded : 0 Total TLVS Unrecognized : 0 Ethernet 1/3 Total Frames Out : 0 Total Entries Aged : 0 Total Frames In : 0 Total Frames Received In Error : 0 Total Frames Discarded : 0 Total TLVS Unrecognized : 0 Ethernet 1/4 Total Frames Out : 0 Total Entries Aged : 0 Total Frames In : 0 Total Frames Received In Error : 0 Total Frames Discarded : 0 Total TLVS Unrecognized : 0</pre>	
Error Messages	N/A	
Related Commands	show lldp	

Enable/Disable LLDP Function

Commands

lldp enable

lldp disable

Syntax Description	lldp Configure LLDP parameters enable Enable LLDP disable Disable LLDP
Defaults	Enable
Command Modes	Privileged EXEC Global Configuration
Usage Guidelines	Enable or disable global LLDP
Examples	<pre>moxa (config)# lldp enable moxa (config)# lldp disable</pre>
Error Messages	N/A
Related Commands	show lldp show lldp interface show lldp neighbors show lldp traffic

Configure Global LLDP Transmission Timer Interval

Commands

lldp transmit-interval <seconds (5-32768)>

no lldp transmit-interval

Syntax Description	no Remove configuration/delete entry/reset to default value lldp Configure LLDP parameters transmit-interval Configure the transmit interval seconds The interval time ranging from 5 to 32768 seconds
Defaults	The interval between successive transmit cycles is set to 30 seconds by default
Command Modes	Privileged EXEC Global Configuration
Usage Guidelines	Configure the global LLDP transmit interval time
Examples	<pre>moxa(config)# lldp transmit-interval 30 moxa(config)# no lldp transmit-interval</pre>
Error Messages	N/A
Related Commands	show lldp config lldp enable

Configure LLDP Holdtime Multiplier

Commands

lldp holdtime-multiplier <value (2-10)>
no lldp holdtime-multiplier

Syntax Description	no	Remove configuration/delete entry/reset to default value
	lldp	Configure LLDP parameters
	holdtime-multiplier	A multiplier on the transmit-interval used to compute the TTL value of txTTL.
	value	The multiplier value ranging from 2 to 10
Defaults	The default holdtime multiplier is set to 4	
Command Modes	Privileged EXEC Global Configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# lldp holdtime-multiplier 4 moxa(config)# no lldp holdtime-multiplier	
Error Messages	N/A	
Related Commands	show lldp config lldp enable	

Ping

Ping the Host

Commands

ping host [repeat repeat-count] [size payload-size] [timeout request-timeout]

Syntax Description	ping Ping a target to check its status host The IP address or domain name of the node to be pinged repeat The number of ping packets that are sent to the destination address repeat-count The repeat value size The size of the ping packet payload-size The length of the ping packet value timeout The time in seconds after which the entity waiting for the ping response times out request-timeout The timeout value
Defaults	N/A
Command Modes	User EXEC Privileged EXEC
Usage Guidelines	N/A
Examples	<pre>moxa# ping 192.168.127.254 repeat 5 PING 192.168.127.254 (192.168.127.254) 56(84) bytes of data. 64 bytes from 192.168.127.254: icmp_seq=1 ttl=64 time=1.52 ms 64 bytes from 192.168.127.254: icmp_seq=2 ttl=64 time=0.803 ms 64 bytes from 192.168.127.254: icmp_seq=3 ttl=64 time=0.879 ms 64 bytes from 192.168.127.254: icmp_seq=4 ttl=64 time=0.791 ms 64 bytes from 192.168.127.254: icmp_seq=5 ttl=64 time=0.845 ms --- 192.168.127.254 ping statistics --- 5 packets transmitted, 5 received, 0% packet loss, time 4002ms rtt min/avg/max/mdev = 0.791/0.968/1.523/0.279 ms</pre>
Error Messages	N/A
Related Commands	N/A

ARP Table

Show IP ARP Table

Commands

show ip arp

Syntax Description	show Display configuration/status information ip Display IP information arp Display the ARP table
Defaults	N/A
Command Modes	User EXEC Privileged EXEC
Usage Guidelines	N/A
Examples	<pre>moxa# show ip arp IP Address MAC Address ----- 192.168.127.113 00:05:1b:a1:ae:62 192.168.127.112 00:05:1b:a3:53:d6</pre>
Error Messages	N/A
Related Commands	N/A

Event Log

Show Logging Event Log

Commands

show logging event-log

Syntax Description	show Display configuration/status information logging Display logging information event-log Display event log entries
Defaults	N/A
Command Modes	Privileged EXEC / User EXEC
Examples	<pre>moxa# show logging event-log Total number of log entries = 7 Boot SEV Timestamp Message ----- 19 5 2018-02-05 12:00:51 [Account:admin] successfully logged in via local. 19 5 2018-02-05 12:00:14 Port 7/4 link up. 19 5 2018-02-05 12:00:12 Port 7/1 link up. 19 5 2018-02-05 12:00:11 Port 7/2 link up. 19 5 2018-02-05 12:00:11 System has performed a warm start. 19 5 2018-02-05 12:00:09 Port 4/3 link up. 19 5 2018-02-05 12:00:08 Port 4/4 link up.</pre>
Help Message	Display the log entries information
Error Messages	N/A
Related Commands	clear logging event-log

Show Logging Log Capacity

Commands

show logging log-capacity

Syntax Description	show	Display configuration/status information
	logging	Display logging information
	log-capacity	Display log capacity information
Defaults	N/A	
Command Modes	Privileged EXEC / User EXEC	
Usage Guidelines	N/A	
Examples	moxa# show logging log-capacity	
Error Messages	N/A	
Related Commands	N/A	

Clear Logging Event Log

Commands

clear logging event-log

Syntax Description	clear	Clear the event
	logging	Display logging information
	event-log	The local event log entries to be cleared
Defaults	N/A	
Command Modes	Privileged EXEC	
Usage Guidelines	N/A	
Examples	moxa# clear logging event-log	
Error Messages	N/A	
Related Commands	show logging event-log	

Export Event Log File

Commands

copy event-log {tftp://server/filename | sftp://<user-name>:<pass-word>@server/filename}

Syntax Description	copy	Copy the target file or input
	event-log	The system event log
	tftp://server/filename	The address of the remote TFTP server in the format "tftp://server/filename"
	sftp://<username>:<password> @server/filename	The address of the remote SFTP server in the format "sftp://username:password@server/filename"
Defaults	N/A	
Command Modes	Privileged EXEC	
Usage Guidelines	N/A	
Examples	moxa# copy event-log tftp://192.168.127.11/test1.log	
Help Message	Copy the system logs to a remote site	
Error Messages	N/A	
Related Commands	show logging event-log	

Configure Event Log Capacity Settings

Commands

logging log-capacity threshold <short (50-100)>

Syntax Description	logging	Configure logging parameters
	log-capacity	Configure the log capacity
	threshold	Configure the log capacity threshold
	short (50-100)	The log capacity threshold in percentage
Defaults	The default log threshold is set to 80 entries	
Command Modes	Privileged EXEC Global Configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# logging log-capacity threshold <short(50-100)>	
Error Messages	N/A	
Related Commands	N/A	

Delete Logging Log Capacity Threshold

Commands

no logging log-capacity threshold

Syntax Description	no	Remove configuration / delete entry / reset to default value
	logging	Configure logging parameters
	log-capacity	Configure the log capacity
	threshold	Configure the log capacity threshold
Defaults	The default log threshold is set to 80 entries	
Command Modes	Privileged EXEC Global Configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# no logging log-capacity threshold	
Error Messages	N/A	
Related Commands	logging log-capacity threshold	

Configure Oversized Log Action Setting

Commands

logging oversize-action { overwrite-oldest | stop-recording }

Syntax Description	logging	Configure logging parameters
	oversize-action	Configure the action when exceeding the log threshold
	overwrite-oldest	Overwrite the oldest entry
	stop-recording	Stop recording events
Defaults	N/A	
Command Modes	Privileged EXEC Global Configuration	
Usage Guidelines	N/A	
Examples	moxa(config)# logging oversize-action { overwrite-oldest stop-recording }	
Error Messages	N/A	
Related Commands	N/A	

Maintenance and Tool

Locator

Show the Locator

Commands

locator [duration]

Syntax Description	locator	Activate the device locator so that the LED on the device blinks
	duration	The duration of locator activation in seconds
Defaults	The locator duration is set to 60 seconds by default	
Command Modes	Privileged EXEC	
Usage Guidelines	N/A	
Examples	moxa# locator 100	
Error Messages	N/A	
Related Commands	N/A	

Reboot

Reboot the Switch

Commands

reload

Syntax Description	reload	Perform a warm restart
Defaults	N/A	
Command Modes	Privileged EXEC	
Usage Guidelines	N/A	
Examples	moxa# reload Are you sure you want to restart the device? [y/N] y Restarting device...	
Error Messages	N/A	
Related Commands	N/A	

Reset to Default

Reset to Default

Commands

reload factory-default

Syntax Description	reload	Perform a warm restart
	factory-default	Perform a warm restart and restore the factory default settings
Defaults	N/A	
Command Modes	Privileged EXEC	
Usage Guidelines	N/A	
Examples	moxa# reload factory-default Would you like to reset system configuration to factory default? [y/N] y Resetting device into factory default and restarting...	
Error Messages	N/A	
Related Commands	N/A	

Logout

Commands

exit

Syntax Description	exit	Log out from the device
Defaults	N/A	
Command Modes	Privileged EXEC	
Usage Guidelines	N/A	
Examples	moxa# exit	
Error messages	N/A	
Related commands	N/A	