


# How to change Network Connection Name

## Purpose:


When you insert new multi network interface card, the Network Connection Name will not be sequenced by Ethernet port in Windows OS. So you can follow below step to change Network Connection Name.

## 1. Change Network Connection Name

1.1. Unplug all of Ethernet connector and switch to Control Panel\Network and Internet\Network Connections and Internet\Network Connections.



- 1.2. Plugged into an Ethernet interface and check the status changes to Connected. Then you can change network connection name.



- 1.3. Repeat step 1.2 to rename other network connection name